



| | |
|---|----------------|
| Doc. No. | Pub. EM-0146-8 |
| Date of issue | July 17, 2013 |
| Products Publicity Section, Sales Administration Dept. | |

Instruction Manual

ASE Series AC Servo Motor-Driven Pumps

Model: ASE3 -*AA-G 80*-B00-31

: ASE5 -*BZ-G130*-B00-31

: ASE10-4CE-G200*-B00-21

- To ensure safe and correct use of the product -

- To ensure proper handling of the product, read this manual thoroughly before use.
- Be sure to follow the instructions described in the Safety Precautions section and the main body of this manual.
- Keep this manual at hand for future reference.
- When creating instruction manuals for systems equipped with the product, be sure to reflect the contents of this manual in such documents.

About this manual




- **Some figures and illustrations in this manual are simplified and may not be an exact representation of the product.**
 - **The contents of this manual are subject to change without prior notice as improvements are made to the product.**
 - **Although this manual has been prepared with great care, please contact the place of purchase or our customer support if you find any ambiguous explanations, errors, or omissions.**
 - **If there are missing pages or erratic pagination in this manual, please contact our customer support. We will replace the manual.**
 - **Reprint, reproduction, or modification of this manual without the permission of YUKEN KOGYO CO., LTD. is prohibited.**
-

■ Safety Precautions

- This manual is intended for users of the product with adequate knowledge of electrics and hydraulics.
- The product should be handled by users having equivalent knowledge as stated above or under the supervision of such personnel.
- Be sure to provide end-users with the instructions, warnings, and cautions described in this manual.
- Be sure to attach this manual when transferring or reselling the product.
- Do not use this product in a residential area.

In this manual, safety precautions are classified into three levels: “DANGER,” “WARNING,” and “CAUTION.” Be sure to read and understand the safety precautions before reading the main body of this manual.

Symbols and definitions for safety precautions in this manual are as follows.

| | | |
|---|----------------|--|
|  | DANGER | Indicates an imminent danger that is very likely to cause death or severe injury if the instructions are ignored. |
|  | WARNING | Indicates a potential danger that may cause death or severe injury if the instructions are ignored. |
|  | CAUTION | Indicates a potential danger that may cause injury or property damage if the instructions are ignored. |

Safety precautions labeled “CAUTION” may result in serious consequences depending on the situation. Regardless of their classification, all safety precautions contain important instructions. Be sure to follow them.

YUKEN KOGYO CO., LTD. assumes no liability for any accident or damage arising from the use or operation of the product in a manner other than specified in this manual.

■ Always follow the safety precautions

DANGER

- Never use the product in an explosive atmosphere where flammable gases or explosives are handled. Doing so may result in a fatal accident, such as fire or explosion.
- Never perform wiring, assembly, or maintenance/inspection work with the product powered on. Doing so may cause electric shock, resulting in a fatal accident.
- Before wiring, installation, relocation, or inspection, shut **off** the power supply and wait 15 minutes or more. When the CHARGE lamp of the AMSE controller turns off, perform a voltage check using a tester and then conduct the work.

WARNING

- Do not use an input power supply not specified. Doing so may cause overheat, resulting in fire.
- Do not modify or disassemble the product. Doing so may impair safe operation.
- Install the AMSE controller and regenerative resistors on nonflammable objects. Any flammable object near them may be heated, causing fire.
- Be sure to connect the ground wire as a precaution against electric shock in the event of earth leakage. Never connect the ground wire to the following.
 - Gas pipe - Lightning rod - Water pipe/faucet - Telephone line ground
- Handling of emergencies
 - If the product begins to smoke

The continuous use of the product under abnormal conditions, such as smoking or unusual odors, may result in fire or electric shock. Immediately shut off the power supply and contact your local customer service after checking that the smoke has stopped. The repair of the product by users is dangerous. The users should never attempt repairs.
 - If the product is broken

If the product is dropped or pulled down, immediately shut off the power supply and contact your local customer service. Continuous use without taking corrective measures may result in fire or electric shock.
 - If water gets into the product

If water gets into the product, immediately shut off the power supply and contact your local customer service. Continuous use without taking corrective measures may result in fire or electric shock.

CAUTION

- Do not put any object in the pump. Doing so may damage the pump's internal parts during operation.
- During operation or for some time after a power-off, the motor frame temperature is high. Prevent hands or other body parts from contacting the frame in order to avoid burn.
- Do not step on or put any heavy object on the product. Doing so may result in damage to the product/equipment or injury from collapse/falling.

■ Table of Contents

| | |
|---|---------|
| 1. Introduction | |
| 1.1 Intended users of the product | P 5 |
| 1.2 Intended purpose | P 5 |
| 1.3 Product check | P 5 |
| 2. About the product | |
| 2.1 Basic structure and components | P 6 |
| 2.2 Basic system configuration | P 7 |
| 2.3 Control system | P 7 |
| 2.4 Model number designation | P 8 |
| 2.5 Specifications | P 9-10 |
| 2.6 External dimensions and mass | P 11-12 |
| 2.7 Interface | P 13-18 |
| 3. Installation of the ASE pump unit | |
| 3.1 Tools for installation | P 19 |
| 3.2 Relocation of the ASE pump unit | P 19 |
| 3.3 Preparation for installation | P 20 |
| 3.4 Installation of the ASE pump unit | P 21 |
| 3.5 Piping | P 22-23 |
| 4. Installation of the AMSE controller | |
| 4.1 Preparation for installation | P 24-25 |
| 4.2 Terminal wiring diagram | P 26 |
| 4.3 Wiring of regenerative resistors | P 27 |
| 4.4 Wiring type | P 28 |
| 5. Preparation for operation | |
| 5.1 Operating environment | P 29 |
| 5.2 Hydraulic fluid | P 29 |
| 5.3 Operation of the ASE pump unit | P 30-31 |
| 6. Operation adjustment | |
| 6.1 Display and operation buttons | P 32 |
| 6.2 Communication cable | P 33 |
| 6.3 Display transitions | P 34 |
| 6.4 Display items | P 35 |
| 6.5 Changing parameter settings | P 36 |
| 6.6 Parameters | P 37-40 |
| 6.7 Parameter functions | P 41-58 |
| 7. Troubleshooting | |
| 7.1 Error indication | P 59-60 |
| 7.2 Measures against alarms (error indication) | P 61-65 |
| 7.3 Measures against noise | P 66-67 |
| 8. Combination use | |
| 8.1 Overview | P 68 |
| 8.2 Simplified diagram of the hydraulic circuit and wiring | P 68 |
| 8.3 Component setting for combination use | P 69 |
| 8.4 Tools for setting | P 70 |
| 8.5 Setting | P 71-72 |
| 8.6 Changing parameters | P 73 |
| 8.7 Before commissioning | P 74-75 |
| 8.8 Troubleshooting during combination use operation | P 76 |
| 8.9 Returning the settings for combination use to single use | P 77 |
| 9. Maintenance | |
| 9.1 Contamination control of hydraulic fluid | P 78 |
| 9.2 Daily inspection | P 78 |
| 9.3 Inspection of the AC servo motor | P 79 |
| 9.4 Guideline for replacing the AC servo motor components | P 79 |
| 9.5 Inspection of the AMSE controller | P 79 |
| 9.6 Guideline for replacing the components of the AMSE controller | P 79 |
| 10. Storage of unused units | P 80 |
| 11. Disposal | P 80 |
| 12. Customer service | P 80 |

1. Introduction

1.1 Intended users of the product

The product should be handled by users with adequate knowledge of electrics and hydraulics or under the supervision of such personnel.

1.2 Intended purpose

The product is a motor-driven pump unit for hydraulic equipment. It generates and supplies hydraulic pressure, mainly as a hydraulic power source for hydraulic equipment.

1.3 Product check

Check the following points upon delivery of the product.

A packaged set of product components is delivered. Be sure to use them as a set.

Please write down and keep their model numbers and serial numbers. This information is important for making inquiries about the product, maintenance, or requesting spare parts.

If there are any questions or problems, please contact the place of purchase or our local customer support.

- Check if the model is correct.

Check the model number marked on the nameplate (refer to “2.4 Model number designation”).

- Check for any damage to the product and/or loose screws.




Fig. 1.3a Product Check

2. About the product

2.1 Basic structure and components




Fig. 2.1a ASE***S-B00*




Fig. 2.1b ASE***B-B00*




Fig. 2.1c AMSE**-B00* (Attached)




Fig. 2.1d Regenerative Resistor (Attached)

2.2 Basic system configuration

The product is a compact and energy-saving hydraulic device comprised of an AC servo motor and a piston pump. This unit can be combined with the dedicated controller to facilitate the configuration of a speed and pressure control system.




Fig. 2.2a Basic System Configuration

2.3 Control system

The control system provides the variable control of pump discharge pressure and flow by controlling the AC servo motor speed according to externally input pressure and flow commands. Pressure control is based on closed-loop control with the feedback of signals from the pressure sensor built in the pump unit.




Fig. 2.3a Control System

2.4 Model number designation

2.4.1 ASE model




Fig. 2.4a Model Number Designation for ASE

2.4.2 Components

Table 2.4a Combination of Components

| Model | AMSE Controller Model | Brake Unit | Regenerative Resistor Model |
|--------|-----------------------|-----------------|--|
| ASE3- | 4AA- | AMSE-4AE-B00-10 | FR-ABR-H15K (indicated on the package) FR-ABR-15K (indicated on the body) |
| | 2AA- | AMSE-2AE-B00-10 | FR-ABR-15K |
| ASE5- | 4BZ- | AMSE-4BB-B00-11 | FR-ABR-H22K × 2 |
| | 2BZ- | AMSE-2BB-B00-11 | FR-ABR-22K × 2 |
| ASE10- | 4CE- | AMSE-4DE-B00-10 | FR-BU2-H30K-04 |
| | | | FR-ABR-H11K-03 × 3 |

2.5 Specifications

Table 2.5a Specifications

| Model | | ASE3-*AA-G80*- | ASE5-*BZ-G130*- | ASE10-4CE-G200*- |
|---------------|-------------------------|---|-----------------|------------------|
| Flow Control | Max. Flow L/min | 80.8 | 132.7 | 205.4 |
| | Min. Controlled Flow | 2 % | | |
| | Hysteresis | 1 % or less | | |
| | Repeatability | 1 % or less | | |
| | Input Signal Voltage *1 | 0 to 6.25 V | 0 to 5.75V | 0 to 5.00V |
| Pres. Control | Pres. Adj. Range MPa | 0.1 to 17.5 | | |
| | Hysteresis | 1 % or less *2 | | |
| | Repeatability | 1 % or less *2 | | |
| | Input Signal Voltage *1 | 0 to 5.0 V | | |
| Atmosphere | | Indoors (no direct sunlight) No corrosive gas, flammable gas, oil mist, or dust. | | |
| Altitude | | 1000 m or less above sea level | | |
| Storage *3 | Ambient Temp. | 0 to 40 °C (no freezing) | | |
| | Ambient Humidity | 80 %RH or less (no condensation) | | |

*1 Default value (allowable maximum input signal voltage: up to 10 V).

*2 Pressure control accuracy depends on system tuning; this value is for reference.

*3 The storage temperature is different from the ambient temperature during operation.

Table 2.5b ASE (Pump) Specifications

| Model | ASE*-*-*-* |
|----------------------|--|
| Operating Pres. | 0.1 to 17.5 MPa |
| Rotational Direction | Clockwise when viewed from the servo motor |
| Hydraulic Fluid | Petroleum based fluid equivalent to ISO VG32 or 46 |
| Viscosity | 20 to 400 mm ² /s |
| Fluid Temp. | 0 to 60 °C |

Table 2.5c AC Servo Motor Specifications

| Model | ASE*-*-*-* | |
|-----------------------------|---|--|
| Insulation Class | Class F | |
| Cooling System | Totally-enclosed forced-cooling | |
| Environmental Condition | Protection | IP44 (except for the shaft through portion) |
| | Ambient Temp. | 0 to 40 °C (no freezing) |
| | Ambient Humidity | 80 %RH or less (no condensation) |
| | Vibration | 24.5 m/s ² or less(When the motor stops, reduce the allowable value to less than one-half.) |
| Fan Power Voltage/Frequency | Single-phase, AC 180 to 220 V, 50/60 Hz | |

Table 2.5d AMSE Controller Specifications


| Model | | AMSE-4AE- (AMSE-2AE-) | AMSE-4BB- (AMSE-2BB-) | AMSE-4DE- |
|-------------------------|-----------------------------------|--|--------------------------|-----------|
| Main Circuit Power | Voltage | 3-phase, AC 380 to 480 V, 50/60 Hz (3-phase, AC 200 to 220 V/50 Hz, AC 200 to 240 V/60 Hz) | | |
| | Permissible Voltage Fluctuation | 3-phase, AC 323 to 528 V, 50/60 Hz (3-phase, AC 170 to 242 V/50 Hz, AC 170 to 264 V/60 Hz) | | |
| | Permissible Frequency Fluctuation | ± 5 % or less | | |
| Interface | Command Signal Input Voltage | 0 to 10 V DC (Pressure/flow command input) | | |
| | Command Signal Input Impedance | 10 kΩ | | |
| | Monitor Output Voltage | 1ch. 0 to 10 V DC (The output can be changed by parameters.) | | |
| | Sequence Input Signal | 12chs. Photocoupler input (current limiting resistance: 4.7 KΩ) Power voltage: DC 21 to 27 V, short-circuited current: 4 to 6 mA | | |
| | Sequence Output Signal | 2chs. Relay output (contact capacity: AC 230 or DC 30 V, 0.3 A) 5chs. Open collector output (permissible load: DC 24 V, 0.1 A) | | |
| Cooling System | | Forced fan cooling, enclosed (IP20) | | |
| Environmental Condition | Ambient Temp. | 0 to 50 °C (no freezing) | | |
| | Ambient Humidity | 90 %RH or less (no condensation) | | |
| | Vibration | 5.9 m/s ² or less | | |
| Protective Functions | | <input type="checkbox"/> Overcurrent <input type="checkbox"/> Regenerative overvoltage <input type="checkbox"/> AMSE controller overload <input type="checkbox"/> Motor overload <input type="checkbox"/> Fan overheat <input type="checkbox"/> Instantaneous power failure <input type="checkbox"/> Undervoltage <input type="checkbox"/> Input open-phase <input type="checkbox"/> Output open-phase <input type="checkbox"/> Stall prevention <input type="checkbox"/> Ground fault overcurrent on the output side <input type="checkbox"/> Communication option error <input type="checkbox"/> Parameter memory device error <input type="checkbox"/> CPU error <input type="checkbox"/> Operation panel power short circuit <input type="checkbox"/> DC 24 power output short circuit <input type="checkbox"/> Inrush current limiting circuit error <input type="checkbox"/> Analog input error <input type="checkbox"/> Fan fault <input type="checkbox"/> Electronic thermal pre-alarm <input type="checkbox"/> Dynamic brake pre-alarm <input type="checkbox"/> PU stop <input type="checkbox"/> Brake transistor error <input type="checkbox"/> Parameter write error <input type="checkbox"/> Copy operation error <input type="checkbox"/> Operation panel lock <input type="checkbox"/> Parameter copy alarm <input type="checkbox"/> Communication error <input type="checkbox"/> USB communication error <input type="checkbox"/> Internal circuit error <input type="checkbox"/> Maintenance signal output <input type="checkbox"/> Error <input type="checkbox"/> Hydraulic control board error <input type="checkbox"/> Hydraulic control board warning | | |

Table 2.5e Facilities

| Model | ASE3- | | ASE5- | | ASE10- |
|------------------------|----------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| | 4AA- | AA- | 4BZ- | BZ- | CE- |
| Power Capacity | 27 kVA | 28 kVA | 41 kVA | | 80 kVA |
| Current Breaker | 100 A frame /60 A | 225 A frame /125 A | 100 A frame /100 A | 225 A frame /175 A | 225 A frame /175 A |
| Electromagnetic Switch | N25 | N50 | N30 | N80 | N80 |

2.6 External dimensions and mass

Table 2.6a Dimensions and Mass of the Motor-Driven Pump




| Model | | | A | B | C | D | E | Φ | Mass kg |
|----------------|----------|----|-----|-----|-------|-----|-------|-----|---------|
| ASE3- | 4AA-G80 | S- | 228 | 284 | 574.5 | 194 | 352.5 | Φ14 | 79 |
| | | B- | 275 | 269 | | | | | |
| | AA-G80 | S- | 228 | 284 | 597.5 | | 352.5 | | 75 |
| | | B- | 275 | 291 | | | | | |
| ASE5- | 4BZ-G130 | S- | 268 | 326 | 670 | 220 | 407.5 | | 116 |
| | | B- | 295 | | | | | | |
| | BZ-G130 | S- | 268 | 378 | 790 | | 479.5 | | 123 |
| | | B- | 295 | | | | | | |
| ASE10-4CE-G200 | | | 340 | 402 | 991 | 296 | 621 | Φ22 | 190 |
| | | | | | | | | | |
| | | | B- | | | | | | |

Unit (ABCDEΦ): mm

*Attention: Use the eyebolt, when the transportation of the product.

MEMO


Table 2.6b Dimensions and Mass of the AMSE Controller and Regenerative Resistor



AMSE Controller

| Model | A | B | C | D | E | Φ | Mass kg |
|-----------|-----|-----|-----|-----|-----|-----|---------|
| AMSE-4AE- | 300 | 220 | 190 | 285 | 195 | Φ6 | 7.5 |
| AMSE-2AE- | 400 | 250 | 190 | 380 | 230 | Φ10 | 14.0 |
| AMSE-4BB- | | | | | | | 13.0 |
| AMSE-2BB- | | | | | | | |
| AMSE-4DE- | 550 | 435 | 250 | 525 | 380 | Φ12 | 35.0 |


Unit (ABCDEΦ): mm



Regenerative Resistor

| Regenerative Resistor | F | G | H | I | J | K | Φ | Mass kg |
|-----------------------|-----|-----|-----|----|------|-----|------|-----------|
| FR-ABR-15K | 100 | 300 | 700 | 50 | 80.5 | 285 | Φ5.3 | 2.2/piece |
| FR-ABR-H22K | | 450 | | | | 435 | | 3.6/piece |
| FR-ABR-H11K-03 | | 400 | | | | 385 | | 3.2/piece |
| FR-ABR-22K | | 400 | | | | | | 3.0/piece |

Unit (FGHIJKΦ): mm



Brake Unit

* ASE10-4CE- Attached

Unit: mm

2.7 Interface

2.7.1 Parts of the AMSE controller (with the cover installed)




Fig. 2.7a Top Face of the AMSE Controller

2.7.2 Removal of the AMSE controller cover

Note) It is dangerous to remove the cover with the controller powered on. Double-check that the controller power is turned off. Before starting wiring work, remove the cover in the following steps. When mounting the cover, take the reverse steps.




Fig. 2.7b Removal of the Cover

2.7.3 Parts of the AMSE controller (internal parts)




Fig. 2.7c Parts of the AMSE Controller

2.7.4 Control circuit terminals

Table 2.7a Sequence Input

| Type | Symbol | Name | Function/Use | Rating | | | | | | | | | | | | | | | | | |
|---------------|----------------------|---|--|---|--------------|--|--------------|----|----|-----|-----|-------------------------|----|-----|-------------------------|-----|----|--------------------------|----|----|-------------------------|
| Contact Input | STF | Forward Rotation Start (Servo-on) | "ON": Forward rotation command "OFF": Stop command | Input resistance: 4.7 KΩ Open-circuit voltage: DC 21 to 27 V Short-circuit voltage: DC 4 to 6 mA | | | | | | | | | | | | | | | | | |
| | STR | Reverse Rotation Start | <Not used.> "ON": Reverse rotation command "OFF": Stop command | | | | | | | | | | | | | | | | | | |
| | STOP | Reserved | Disabled. | | | | | | | | | | | | | | | | | | |
| | RH | Control Code x 1 | Switches the gain according to the load condition variable for each process. <table border="1"> <thead> <tr> <th colspan="2">Input Signal</th> <th rowspan="2">Control Code</th> </tr> <tr> <th>RH</th> <th>RM</th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>OFF</td> <td>No. 0 control parameter</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>No. 1 control parameter</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>No. 2L control parameter</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>No. 3 control parameter</td> </tr> </tbody> </table> | | Input Signal | | Control Code | RH | RM | OFF | OFF | No. 0 control parameter | ON | OFF | No. 1 control parameter | OFF | ON | No. 2L control parameter | ON | ON | No. 3 control parameter |
| | Input Signal | | Control Code | | | | | | | | | | | | | | | | | | |
| | RH | RM | | | | | | | | | | | | | | | | | | | |
| | OFF | OFF | No. 0 control parameter | | | | | | | | | | | | | | | | | | |
| | ON | OFF | No. 1 control parameter | | | | | | | | | | | | | | | | | | |
| | OFF | ON | No. 2L control parameter | | | | | | | | | | | | | | | | | | |
| | ON | ON | No. 3 control parameter | | | | | | | | | | | | | | | | | | |
| | RM | Control Code x 2 | | | | | | | | | | | | | | | | | | | |
| | JOG | Reserved | Disabled. | | | | | | | | | | | | | | | | | | |
| | RT | Reserved | Disabled. | | | | | | | | | | | | | | | | | | |
| MRS | Emergency Stop | "OFF": Emergency stop "ON": Emergency stop reset | | | | | | | | | | | | | | | | | | | |
| RES | Reset | Resets an alarm. | | | | | | | | | | | | | | | | | | | |
| AU | Reserved | Disabled. | | | | | | | | | | | | | | | | | | | |
| CS | Reserved | Disabled. | | | | | | | | | | | | | | | | | | | |
| SD | Contact Input Common | Common terminal for contact input terminals. Note) This terminal is insulated from Terminals "5" and "SE." | - | | | | | | | | | | | | | | | | | | |
| PC | DC 24 V Power Output | This terminal can be used to supply DC 24 V, 0.1 A power. | Power voltage range: DC 20 to 28 V Permissible load current: 100 mA | | | | | | | | | | | | | | | | | | |




Fig. 2.7d Simplified Wiring Diagram

⚠ WARNING

- ◆ When the servo is turned "ON", there is a possibility that the device moves spontaneously. Therefore, the preventive measure is required to secure the servo is not turned "ON" until confirm the safety of device. If the device moves spontaneously, there is a a risk of human death or severe injury.

Table 2.7b Analog I/O

| Type | Symbol | Name | Function/Use | Rating | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------------|--|---|---|---|-----------------|------|------------------------------|---|---|------------------|-----|---|--------------|-----|---|-------------------------|-----|---|--|-----|---|--------------|-----|---|--------------------------------|-----|--|
| Flow/Pressure Setting | 10E | DC 10 V Power Output | This terminal can be used to supply DC 10 V, 10 mA power. | DC 10 ± 0.4 V Permissible load current: 10mA | | | | | | | | | | | | | | | | | | | | | | | |
| | 10 | DC 5 V Power Output | This terminal can be used to supply DC 5 V, 10 mA power. | DC 5.2 ± 0.2 V Permissible load current: 10 mA | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Pressure Command Voltage | A voltage of DC 0 to + 5 V (max. 10 V) is applied between Terminals "2" and "5." The span of the command voltage is set by the parameter below. <table border="1"> <thead> <tr> <th>Parameter No.</th> <th>Rated Pressure</th> </tr> </thead> <tbody> <tr> <td>P460</td> <td>Default: 175 [× 0.1 MPa/5 V]</td> </tr> </tbody> </table> * See "Table 6.7n" for setting. | Parameter No. | Rated Pressure | P460 | Default: 175 [× 0.1 MPa/5 V] | Input resistance: 10 ± 1 kΩ Permissible voltage: DC 20 V | | | | | | | | | | | | | | | | | | | |
| | Parameter No. | Rated Pressure | | | | | | | | | | | | | | | | | | | | | | | | | |
| | P460 | Default: 175 [× 0.1 MPa/5 V] | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 4 | Flow Command Voltage | A voltage of DC 0 to + 5 V (max. 10 V) is applied between Terminals "4" and "5." The span of the command voltage is set by the parameter below. <table border="1"> <thead> <tr> <th>Parameter No.</th> <th>Rated Flow Rate</th> </tr> </thead> <tbody> <tr> <td>P461</td> <td>Default: 2000 [rpm/5 V]</td> </tr> </tbody> </table> * See "Table 6.7n" for setting. | Parameter No. | Rated Flow Rate | P461 | Default: 2000 [rpm/5 V] | | | | | | | | | | | | | | | | | | | | |
| | Parameter No. | Rated Flow Rate | | | | | | | | | | | | | | | | | | | | | | | | | |
| P461 | Default: 2000 [rpm/5 V] | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Control Common | Common terminal for command voltage and monitoring voltage. | - | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Reserved | Not used. Do not connect wiring. | - | | | | | | | | | | | | | | | | | | | | | | | | |
| AM | General Monitor | Selects and outputs monitoring items. The setting parameter "P463: AM Monitoring Output Item Selection" can be used to check the output of the following items. <table border="1"> <thead> <tr> <th>Setting</th> <th>Output Name</th> <th>Symbol</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Motor Speed Command</td> <td>Vref</td> </tr> <tr> <td>1</td> <td>Pressure Command</td> <td>PIN</td> </tr> <tr> <td>2</td> <td>Flow Command</td> <td>QIN</td> </tr> <tr> <td>3</td> <td>Pressure Sensor Monitor</td> <td>SMP</td> </tr> <tr> <td>4</td> <td>Motor Speed Monitor (Calculated Value)</td> <td>SMN</td> </tr> <tr> <td>5</td> <td>Motor Torque</td> <td>TRQ</td> </tr> <tr> <td>6</td> <td>Electronic Thermal Load Factor</td> <td>SMF</td> </tr> </tbody> </table> | Setting | Output Name | Symbol | 0 | Motor Speed Command | Vref | 1 | Pressure Command | PIN | 2 | Flow Command | QIN | 3 | Pressure Sensor Monitor | SMP | 4 | Motor Speed Monitor (Calculated Value) | SMN | 5 | Motor Torque | TRQ | 6 | Electronic Thermal Load Factor | SMF | Output signal: DC 0 to 10 V Permissible load current: 1 mA Load impedance: 10 kΩ or more Resolution: 8 bits |
| Setting | Output Name | Symbol | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Motor Speed Command | Vref | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Pressure Command | PIN | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Flow Command | QIN | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Pressure Sensor Monitor | SMP | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Motor Speed Monitor (Calculated Value) | SMN | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Motor Torque | TRQ | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Electronic Thermal Load Factor | SMF | | | | | | | | | | | | | | | | | | | | | | | | | |

Table 2.7c Error Output

| Type | Symbol | Name | Function/Use | Rating |
|----------------------|--------|----------------------------|---|--|
| Relay Contact Output | A1 | Warning Output - Contact B | This contact output indicates that the AMSE controller's warning function is activated. Warning: Continuity between B and C (discontinuity between A and C) Normal: Discontinuity between B and C (continuity between A and C) | Contact capacity: AC 230 V, 0.3 A DC 30 V, 0.3 A |
| | B1 | Warning Output - Contact A | | |
| | C1 | Warning Output - Common | | |
| | A2 | Alarm Output - Contact B | This contact output indicates that the AMSE controller's alarm function is activated to stop the output. Warning: Continuity between B and C (discontinuity between A and C) Normal: Discontinuity between B and C (continuity between A and C) | |
| | B2 | Alarm Output - Contact A | | |
| | C2 | Alarm Output - Common | | |

Table 2.7d Sequence Output

| Type | Symbol | Name | Function/Use | Rating | | | |
|-----------------------|------------------------------|--|--|--|--|-----|--|
| Open Collector Output | RUN | Operation Ready | Turned "on" when STF/STR is "on" and the unit is ready to run with a flow/pressure command. | Permissible load: DC 24 V, 0.1 A (max. DC 27 V) * Max. voltage drop with "on": 2.8 V | | | |
| | OL | Swash Plate Angle Large | Not used. | | | | |
| | IPF | Alarm Code - 0 | Outputs a 3-bit code to describe an alarm when the AMSE controller's protection function is activated to stop the output. | | | | |
| | SU | Alarm Code - 1 | | | | | |
| | FU | Alarm Code - 2 | Output Terminal Symbol | | | | |
| | | | FU | | SU | IPF | Description |
| | | | OFF | | OFF | OFF | <input type="checkbox"/> Parameter memory device error <input type="checkbox"/> CPU error <input type="checkbox"/> Inrush current limiting circuit error <input type="checkbox"/> Analog input error <input type="checkbox"/> Option error <input type="checkbox"/> Communication error <input type="checkbox"/> Internal circuit error <input type="checkbox"/> DC 24 power output short circuit <input type="checkbox"/> Operation panel power short circuit <input type="checkbox"/> USB communication error <input type="checkbox"/> Hydraulic control board error |
| | | | OFF | | OFF | ON | <input type="checkbox"/> Regenerative overvoltage <input type="checkbox"/> Brake transistor error detection |
| | | | OFF | | ON | OFF | <input type="checkbox"/> Undervoltage <input type="checkbox"/> Instantaneous power failure |
| | | | OFF | | ON | ON | <input type="checkbox"/> AMSE controller overload <input type="checkbox"/> Motor overload <input type="checkbox"/> Fin overheat <input type="checkbox"/> Stall prevention |
| ON | | | OFF | OFF | <input type="checkbox"/> Overcurrent <input type="checkbox"/> Ground fault overcurrent on the output side | | |
| ON | ON | ON | <input type="checkbox"/> Input open-phase <input type="checkbox"/> Output open-phase <input type="checkbox"/> PU disconnection | | | | |
| SE | Open Collector Output Common | Common terminals for RUN, OL, IPF, SU, and FU. | - | | | | |

Table 2.7e Others

| Type | Symbol | Name | Function/Use | Rating |
|------|--------|------|----------------------------------|--------|
| | FM | - | Not used. Do not connect wiring. | - |


2.7.5 Sensor terminals

Table 2.7f Pressure Sensor/Thermistor Terminals

| Type | Symbol | Name | Function/Use |
|---------------------|--------|------------------------------|--|
| Analog I/O Terminal | 1 | Pressure Sensor Power Supply | Supplies DC 4.9 to 5.2 V power to the pressure sensor. |
| | 2 | Pressure Sensor Input | Receives the output voltage of the pressure sensor. (0.5 to 4.5 V = 0 to 35 MPa) |
| | 3 | Pressure Sensor Common | Common terminal for the pressure sensor. |
| | 4 | Pressure Sensor Shield | Wiring for a measure against radiated noise. |
| | 5 | Thermistor Input - 1 | Receives the output voltage of the sensor for monitoring the motor's internal temperature. |
| | 6 | Thermistor Input - 2 | |
| | 7 | Reserved | |


2.7.6 Main circuit terminals

Table 2.7g Main Circuit Terminals

| Type | Symbol | Name | Function/Use |
|--------------------------|---|----------------------------------|---|
| High Voltage Power Cable | R/L1 | AC Power Input | Connects to a commercial power supply - AMSE-4**-**-* : 3-phase AC 380 to 480 V - AMSE-**-**-* : 3-phase AC 200 to 220 V / 50Hz : 3-phase AC 200 to 240 V / 60Hz |
| | S/L2 | | |
| | T/L3 | | |
| | U | Motor Output | Connects to the motor. Note) Match the U, V, and W phases for cable connection. |
| | V | | |
| | W | | |
| | N/- | Not connected | Connection is not required. |
| | P1 | Not connected | Short-circuited to P/+. Do not remove the short bar. |
| | P/+ | Regenerative Resistor Connection | Connects to the attached regenerative resistor. * The wiring method (series or parallel) varies depending on the models. |
| | PR | Regenerative Resistor Connection | |
| |  | Ground | Be sure to connect the ground wire. |

2.7.7 Control power terminals

The main circuit terminals R/L1 and S/L2 are internally connected with R1/L11 and S1/L21 (control power terminals in the lower low). By default, the lower terminal block is connected with the upper terminal block (control power terminals) via short bars; the control power is turned on at the same time as the main circuit power is turned on. To keep the control power active at the time of error detection, remove both short bars (shown below) and provide the control power separately.



3. Installation of the ASE pump unit

3.1 Tools for installation

Prepare the tool listed below.

Table 3.1a Tool for Pump Installation

| Model | Tool (Size) |
|---------|------------------------------------|
| ASE3/5- | Wrench (width across flats: 19 mm) |
| ASE10- | Wrench (width across flats: 22 mm) |

Table 3.1b Tool for Suction Pipe Flange Connection

| Model | Tool (Size) |
|------------|--|
| ASE3/5/10- | Allen wrench (width across flats: 10 mm) |

Table 3.1c Tool for Discharge Pipe Flange Connection

| Model | Tool (Size) |
|------------|---|
| ASE3/5/10- | Allen wrench (width across flats: 8 mm) |

Table 3.1d Filling Port

| Model | Tool (Size) |
|------------|------------------------------------|
| ASE3/5/10- | Wrench (width across flats: 22 mm) |

3.2 Relocation of the ASE pump unit

Take great care not to drop, knock over, or damage the product during transport.



CAUTION

- ◆ Never lift or carry the product in an incorrect posture. Pinching of hands or backache may occur depending on the product mass or the posture of the worker.
- ◆ Do not step on or put any heavy object on the product. Doing so may result in damage to the product/equipment or injury from slipping/falling.

3.3 Preparation for installation

- a) Before starting installation work, clean and dust the working area, hands, and clothing to prevent foreign matter from entering the product/equipment.
- b) Remove the protective plug from the port and the protective plates from the port flange mounting surface. When removing the plates, be careful not to damage the mounting surface.




Fig. 3.3a Removal of the Protective Plug and Plates

- c) Check for critical scratches on the O-ring sealing surface of each port and the port flange mounting surface. If any scratch is found, eliminate it by mending the mounting surface. If a critical scratch that cannot be mended is found, contact our customer support.



CAUTION

- ◆ Any critical scratch on the mounting surface may cause fluid leakage, resulting in a major accident.

- d) Clean the O-ring sealing surface of each port and the port flange mounting surface to ensure that there is no foreign matter, such as metal debris and lint from waste cloth.
- e) Check for critical scratches on the O-ring mounting surface of the pipe flange and check that the O-ring is properly mounted in the groove. If required, mount it in the groove correctly.



CAUTION

- ◆ Improper mounting of the O-rings may cause damage to them or outflow of hydraulic fluid, resulting in a major accident.

3.4 Installation of the ASE pump unit

3.4.1 Installation position

- Install the unit with the filling port facing upward.
- Bolt the unit securely using the mounting holes on the bracket.




Fig. 3.4a Installation Example



CAUTION

- ◆ Improper mounting condition of foot bracket, may increase noise level during operation. In such case, use the anti-vibration rubber or acoustic absorbent to cover the foot bracket and take appropriate measures. Continuing the operation under such condition may result in human injury.

3.4.2 Bolting

Screw in the bolts listed below gradually and evenly.

Note) Use the washers to prevent the bolts from loosening.

Table 3.4a Bolt Size and Tightening Torque

| Model | Bolt Size | Quantity | Tightening Torque N•m |
|---------|---|----------|-----------------------|
| ASE3/5- | JIS B1180 Hexagon Head Bolt M12 (Strength Grade: 6.8 or more) | 4 | 50 to 55 |
| ASE10- | JIS B 1180 Hexagon Head Bolt M20 (Strength Grade: 6.8 or more) | 4 | 232 to 256 |



WARNING

- ◆ Use the specified number of bolts of the same material/strength grade and apply the specified tightening torque. Failure to do so may cause damage to the bolts or outflow of hydraulic fluid, resulting in a major accident.

3.5.3 Pipe tightening

The pipe tightening torque is shown in Table 3.5c.

⚠ WARNING

- ◆ Apply the pipe tightening torque as specified. Failure to do so may cause damage to the screws or outflow of hydraulic fluid, resulting in a major accident.

Table 3.5c Screw Size and Tightening Torque

| | Model | Screw Size | Tightening Torque[Nm] |
|----------------|------------|---|-----------------------|
| Discharge Pipe | ASE3/5/10- | Port Flange Screw: JIS B1176 Hexagon Socket Head Cap Screw M10 (Strength Grade: 12.9) | 61 to 74 |
| Suction Pipe | ASE3/5/10- | Port Flange Screw: JIS B1176 Hexagon Socket Head Cap Screw M12 (Strength Grade: 12.9) | 104 to 127 |
| Drain Pipe | ASE3/5- | Rc1/2 | 52 to 95 |
| | ASE10- | Rc3/4 | 90 to 165 |

When using four screws for the suction pipe flange, tighten them gradually and evenly in the order shown by the numbers 1 to 4 in Fig. 3.5a and repeat this cycle two or three times.




Fig. 3.5a Screw Tightening

⚠ WARNING

- ◆ Do not tighten the screws with the O-rings mounted improperly. Doing so may cause damage to the O-rings or outflow of hydraulic fluid, resulting in a major accident.

When using steel pipes, they may place excessive load on the motor-driven pump unit, resulting in noise. If there is a possibility that steel pipes may place such load on the unit, use rubber hoses.

4. Installation of the AMSE controller

4.1 Preparation for installation



CAUTION

- ◆ The AMSE controller is fan-cooled. Be sure to observe the following installation standards and pay attention to the circulation of air.

4.1.1 Installation standards (the values below indicate minimum clearances.)




Fig. 4.1a Installation Standards

4.1.2 Installation orientation

Install the AMSE controller vertically on the wall with its front face (with the operator panel) facing toward the operator.

4.1.3 Cooling

With reference to Fig. 4.1a, leave enough space around the AMSE controller to allow cooling by the fan and natural convection.

The cooling fan is required to keep the temperature in the control panel uniform so that the ambient temperature around the AMSE controller does not locally increase.

4.1.4 Environmental condition in the control panel

Ambient temperature around the AMSE controller: 0 to 50 °C

Humidity: 90 %RH (relative humidity) or less

Vibration: 5.9 m/s² or less

No freezing or condensation is permitted. Operation at an ambient temperature of 45 °C or less is recommended to ensure operational reliability for a long term.

4.1.5 Installation of regenerative resistors

- * Double-check the model and quantity of regenerative resistors prior to installation.
- * Be sure to use all regenerative resistors supplied with the unit.
- * Regenerative resistors may be excessively heated. Use heat-resistant and fireproof wires and avoid their contact with the resistors.
- * If the regeneration capacity exceeding the standard specification level is required, regenerative resistors must be exchanged. Consult us separately.
- * Pay attention to the installation standards below (Fig. 4.1b).

Table 4.1a Regenerative Resistor

| Applicable Model | Regenerative Resistor Model | | Capacity W | Mass kg | Supplied Quantity |
|------------------|-----------------------------|-----------------------|------------|-----------|-------------------|
| | Indicated on the package | Indicated on the body | | | |
| AMSE- | 4AE- | FR-ABR-H15K | 402/piece | 2.2/piece | 2 |
| | 2AE- | FR-ABR-15K | | | |
| AMSE- | 4BB- | FR-ABR-H22K | 530/piece | 3.6/piece | |
| | 2BB- | FR-ABR-22K | 560/piece | 3.0/piece | |
| AMSE-4DE- | FR-ABR-11K-03 | | 560/piece | 3.2/piece | |




Fig. 4.1b Regenerative Resistor Installation Standards




Fig. 4.1c Brake Unit Installation Standards (ASE10-4CE- Attached)

4.2 Terminal wiring diagram




Fig. 4.2a Wiring Diagram

4.3 Wiring of regenerative resistors




Fig. 4.3a Wiring Diagram of Regenerative Resistors

4.4 Wiring type

Table 4.4a Main Circuit Terminal Wiring Types

| AMSE- | Item | Main Circuit Terminal Block | | | |
|------------------------|-------------------------|--------------------------------------|------------------------------|----------------|---|
| | | AC Power Input (R/L1, S/L2, T/L3) | Motor Output (U, V, W) | Ground Wire | Regenerative Resistor (P/+, N/-, -PR) |
| 4AE- | Wire (mm ²) | 8 (AWG8) | | | 2.1 (AWG14) |
| | Screw Size | M5 | | | |
| | Tightening Torque | 2.5 N•m | | | |
| 2AE- | Wire (mm ²) | 22 (AWG4) | | 14 (AWG6) | 2.1 (AWG14) |
| | Screw Size | M6 | | | |
| | Tightening Torque | 4.4 N•m | | | |
| 4BB- | Wire (mm ²) | 14 (AWG6) | | | 2.1 (AWG14) |
| | Screw Size | M6 | | | |
| | Tightening Torque | 4.4 N•m | | | |
| 2BB- | Wire (mm ²) | 38 (AWG2) | | 22 (AWG2) | 2.1 (AWG14) |
| | Screw Size | M8 | | | |
| | Tightening Torque | 7.8 N•m | | | |
| 4DE | Wire (mm ²) | 38 (AWG1) | | 38 (AWG2) | 3.5 (AWG12) |
| | Screw Size | M8 | | | |
| | Tightening Torque | 7.8 N•m | | | |
| FR-BU2 -H30K-0 4 | Wire (mm ²) | - | | | 3.5 (AWG12) |
| | Screw Size | - | | | |
| | Tightening Torque | - | | | |

Table 4.4b Control Circuit Terminal/Sensor Terminal Wiring Types

| | Item | Control Circuit Terminal Block | Sensor Terminal Block |
|-------|-------------------------|--------------------------------|--------------------------|
| AMSE- | Wire (mm ²) | 0.75 to 2.1 (AWG18 to 14) | 0.5 to 1.3 (AWG20 to 16) |
| | Screw Size | M3.5 | Push lock type |
| | Tightening Torque | 1.2 N•m | - |

MEMO

5. Preparation for operation

5.1 Operating environment

Use the product as a hydraulic power source for hydraulic equipment.

Operate it under the conditions below. Operation in other conditions may result in malfunction.

- Installation location: Indoor environment free of combustible/corrosive/flammable gas or mist that meets the following requirements.
 - Ambient environment: See Sections 2.5 (Specifications), 3 (Installation of the ASE pump unit), and 4 (Installation of the AMSE controller).
 - No obstruction that may prevent ventilation or make the nameplate invisible.
 - The product is not waterproof and must not be used in water.



DANGER

- ◆ Never use the product in an explosive atmosphere, including locations where flammable gases or explosives are handled. Doing so may result in fire, explosion, or any other serious and fatal accident.

5.2 Hydraulic fluid



CAUTION

- ◆ Use proper hydraulic fluid within the specified ranges of fluid temperature, viscosity, and contamination level. Failure to do so may result in malfunction or fluid leakage, causing fire.

5.2.1 Fluid type

- Petroleum based hydraulic fluid: Use a hydraulic fluid equivalent to ISO VG32 or 46.
 Note) To use a hydraulic fluid other than petroleum based one (synthetic fluid, water based fluid, etc.), consult us separately.

5.2.2 Fluid viscosity and temperature

Meet the following requirements for fluid viscosity and temperature during operation.

Viscosity: 20 to 400 mm²/s

Fluid temperature: 0 to 60 °C

5.2.3 Prevention of foreign matter invasion

Foreign matter entering hydraulic fluid may result in a shorter service life or failure of the pump. Always keep the fluid clean (contamination level: JIS B9933 (ISO 4406) 20/18/14 or NAS 9 or better).

5.3.1 Initial operation

**CAUTION**

- ◆ Upon initial operation, check in advance that the hydraulic circuit and electric wiring have been correctly installed and that fastened parts are not loose.

- a) Pour clean hydraulic fluid through the filling port into the pump.
Failure to do so may cause seizing of or damage to the parts.

Table 5.3a Fluid Filling Quantity for Each Model

| Model | Filling Quantity |
|-----------|---------------------|
| ASE3-*AA- | 600 cm ³ |
| ASE5-*BZ- | |
| ASE10-*CE | 900 cm ³ |





Fig. 5.3a Hydraulic Fluid Filling

- b) Adjust the control valves so that the pump discharge fluid circulates directly into the tank or so that the actuator runs with no load.
Note) Do not start the pump with its discharge blocked.
- c) Operate the pump under the following recommended conditions and check the points below.
<Power-on procedure>
Start and run the ASE pump unit as follows.
Turn “on” the main circuit power and wait three seconds -> Turn “on” the servo (“on” between the terminals STF and SD).
* Turning on the servo within three seconds after turning on the main circuit power may cause malfunction. Follow the specified procedures to avoid a possibility of causing human suffering.
- <Recommended operating conditions>
Motor speed: 1000 r/min or less
Pressure: 5 MPa or less
- <Check items>
Check if the pump sucks fluid normally.
Be aware that the motor may rotate in the reverse direction due to wrong wiring of the U, V, and W phases between the AMSE controller and the motor.
- d) After checking that there is no problem in Step c), perform the test run and air-bleed the system.
Note) Upon pump startup, air enters hydraulic fluid and causes noise, but this phenomenon is not an indication of failure. If the noise is not eliminated, air-bleed the circuit.

6. Operation adjustment

6.1 Display and operation buttons

The AMSE controller allows status display and parameter setting for the ASE pump unit. It has a 4-digit LED display to facilitate checking the output and parameters.



Setting Buttons

| Symbol | Use | Description |
|------------|----------------------|---|
| PU/EXT | <Not Used> | Operating these buttons has no effect. |
| REV | <Not Used> | |
| FWD | <Not Used> | |
| MODE | Mode Switching | Switches between the setting modes. |
| SET | Setting Confirmation | Confirms settings. Pressing this button during operation switches the monitor display as follows. "Motor Speed" -> "Output Current" -> "Output Voltage" |
| STOP/RESET | Alarm Reset | Resets alarms. When the setting of the setting parameter "P_75" is changed, "STOP" (Motor Stop) is enabled. |

Fig. 6.1a Display and Operation Buttons

6.3 Display transitions

- At the time of power-on, the display appears as shown in Fig. 6.3a.
- By default, the motor speed is displayed.





Fig. 6.3a Operation Panel




Fig. 6.3b Display Transition Chart

6.4 Display items

Table 6.4a Display Items

Note) “*” represents a number, and “□” represents a code.

| Code | Name | Description | Reference |
|-------------|--|--|---|
| P*** | Setting Parameters | Changes settings. | Tables 6.6a to c: Setting Parameters |
| C** | Calibration Parameters | Calibrates signals. | Table 6.6d: Setting Parameters |
| Pr.CL | Parameter Clear | Initializes a parameter. | Table 6.6c: Setting Parameters |
| ALLC | All Parameter Clear | Initializes all parameters. | |
| Er.CL | <Alarm Clear> (Manufacturer-controlled) | <Alarm History Clear> (manufacturer-controlled). | |
| PCPY | Parameter Copy | Copies setting parameter data when using multiple AMSE controllers. | |
| E.□□□ | Alarms | Error detection. | Table 7.1a: Alarm Codes |
| OL | Stall Prevention (Overcurrent) | Warnings. | Table 7.1b: Warnings |
| Rb | Dynamic Brake Pre-alarm | | |
| ГH | Electronic Thermal Pre-alarm | | |
| PS | PU Stop | | |
| CP | Parameter Copy | | |
| Fn | Fan Fault | | |
| oP | Hydraulic Control Board Warning | | |
| HOLD | Operation Panel Lock | Operation errors. | Table 7.1c: Error Messages |
| Er * | Warnings | | |
| rE * Err | Error Messages | | |
| P 5 | Operation Panel Command Stopped | Indicates that operation has been stopped by the “STOP/RESET” button on the operation panel. | Table 7.1d: Status Display |
| EPG | Emergency Stop | Indicates that operation has been stopped by the emergency stop procedure. | |

MEMO

6.5 Changing parameter settings

1) Turn on the power (the motor speed is displayed).



2) Enable the parameter setting mode.

A) Press the "MODE" button.




B) Check that "P" appears on the monitor.




When "P" is not displayed, turn the "M Dial" until "P" appears.

C) Turn the "M Dial" to display the target parameter No, and then press the "SET" button. The currently set value is displayed.



D) Turn the "M Dial" to change the value, and then press the "SET" button. The parameter No. and the set value are displayed alternately to indicate that the setting has been confirmed.



E) Press the "MODE" button twice to return to the initial display.

6.6 Parameters

Note) Never change the settings of manufacturer-controlled parameters.

Table 6.6a Setting Parameters “P***”

| No. | Name | Setting Range | Minimum Setting Unit | Default | Reference |
|------|--|---|----------------------|------------------------|------------|
| P 1 | Upper Limit Frequency | 0 to 3000 r/min | 1 r/min | (Depends on the model) | Table 6.7a |
| P 2 | Manufacturer-controlled | - | - | 0 | |
| P 7 | Acceleration Time | 0 to 15 s | 0.01 s | 0.04 | |
| P 8 | Deceleration Time | 0 to 15 s | 0.01 s | 0.04 | |
| P 9 | Manufacturer-controlled | - | - | (Depends on the model) | |
| P 10 | Manufacturer-controlled | - | - | 8 | |
| P 13 | Manufacturer-controlled | - | - | 0 | |
| P 17 | MRS Input Selection | 0, 2 | 1 | 2 | |
| P 20 | Manufacturer-controlled | - | - | 1500 | |
| P 22 | Manufacturer-controlled | - | - | 200.0 | |
| P 30 | Manufacturer-controlled | - | - | 1 | |
| P 52 | DU/PU Main Display Data Selection | 0, 5 to 14, 17, 20, 23, 25, 55, 81 to 86, 100 | 1 | 0 | Table 6.7b |
| P 54 | Manufacturer-controlled | - | - | 1 | Table 6.7c |
| P 55 | Manufacturer-controlled | - | - | 2250 | |
| P 56 | Manufacturer-controlled | - | - | (Depends on the model) | |
| P 70 | Manufacturer-controlled | - | - | 6.0 | |
| P 71 | Manufacturer-controlled | - | - | 150 | |
| P 72 | Manufacturer-controlled | - | - | 6 | |
| P 75 | Reset/PU Disconnection/PU Stop Selection | 0 to 3, 14 to 17 | 1 | 1 | |
| P 77 | Parameter Write Selection | 0, 1, 2 | 1 | 2 | |
| P 79 | Manufacturer-controlled | - | - | 2 | |
| P 80 | Manufacturer-controlled | - | - | (Depends on the model) | |
| P 81 | Manufacturer-controlled | - | - | 8 | Table 6.7d |
| P144 | Manufacturer-controlled | - | - | 108 | |
| P145 | Manufacturer-controlled | - | - | 0 | |
| P161 | Button Lock Operation Selection | 0, 1, 10, 11 | 1 | 10 | |
| P168 | (Read-only, write-protected) | | | - | |
| P169 | (Read-only, write-protected) | | | - | |
| P240 | Manufacturer-controlled | - | - | 0 | |
| P244 | Cooling Fan Operation Selection | 0, 1 | 1 | 1 | |
| P251 | Manufacturer-controlled | - | - | 1 | Table 6.7e |
| P255 | Life Warning Status Display | (0 to 15), read-only | 1 | 0 | |
| P256 | Inrush Current Limiting Circuit Life Display | (0 to 100), read-only | 1 % | 100 | |
| P257 | Control Circuit Capacitor Life Display | (0 to 100), read-only | 1 % | 100 | |
| P258 | Main Circuit Capacitor Life Display | (0 to 100), read-only | 1 % | 100 | |
| P259 | Main Circuit Capacitor Life Measurement | 0, 1 (2, 3, 8, 9) | 1 | 0 | |
| P331 | Manufacturer-controlled | - | - | 0 | |
| P332 | Manufacturer-controlled | - | - | 96 | |
| P333 | Manufacturer-controlled | - | - | 1 | |
| P334 | Manufacturer-controlled | - | - | 2 | |
| P335 | Manufacturer-controlled | - | - | 1 | |
| P336 | Manufacturer-controlled | - | - | 0.0 | |
| P337 | Manufacturer-controlled | - | - | 9999 | |
| P338 | Manufacturer-controlled | - | - | 0 | |
| P339 | Manufacturer-controlled | - | - | 0 | |

Table 6.6b Setting Parameters “P***”

| No. | Name | Setting Range | Minimum Setting Unit | Default | Reference |
|------|---|---------------|----------------------|---------|------------|
| P340 | Manufacturer-controlled | - | - | 0 | - |
| P341 | Manufacturer-controlled | - | - | 1 | |
| P342 | Manufacturer-controlled | - | - | 0 | |
| P402 | No. 0 Rise Time Gain | 0 to 9999 | 1 | 1500 | Table 6.7h |
| P403 | No. 0 Fall Time Gain | 0 to 9999 | 1 | 1500 | |
| P404 | No. 0 Lag Compensation | 1 to 2000 | 1 | 70 | Table 6.7i |
| P405 | No. 0 Lead Compensation | 1 to 2000 | 1 | 60 | |
| P406 | No. 0 Rise Time Pressure Command Filter | 1 to 2000 | 1 | 300 | Table 6.7j |
| P407 | No. 0 Fall Time Pressure Command Filter | 1 to 2000 | 1 | 300 | |
| P408 | No. 0 Pressure Response Sensitivity | 1 to 2000 | 1 | 200 | Table 6.7k |
| P409 | No. 1 Rise Time Gain | 0 to 9999 | 1 | 1500 | Table 6.7h |
| P410 | No. 1 Fall Time Gain | 0 to 9999 | 1 | 1500 | |
| P411 | No. 1 Lag Compensation | 1 to 2000 | 1 | 70 | Table 6.7i |
| P412 | No. 1 Lead Compensation | 1 to 2000 | 1 | 60 | |
| P413 | No. 1 Rise Time Pressure Command Filter | 1 to 2000 | 1 | 300 | Table 6.7j |
| P414 | No. 1 Fall Time Pressure Command Filter | 1 to 2000 | 1 | 300 | |
| P415 | No. 1 Pressure Response Sensitivity | 1 to 2000 | 1 | 200 | Table 6.7k |
| P416 | No. 2 Rise Time Gain | 0 to 9999 | 1 | 1500 | Table 6.7h |
| P417 | No. 2 Fall Time Gain | 0 to 9999 | 1 | 1500 | |
| P418 | No. 2 Lag Compensation | 1 to 2000 | 1 | 70 | Table 6.7i |
| P419 | No. 2 Lead Compensation | 1 to 2000 | 1 | 60 | |
| P420 | No. 2 Rise Time Pressure Command Filter | 1 to 2000 | 1 | 300 | Table 6.7j |
| P421 | No. 2 Fall Time Pressure Command Filter | 1 to 2000 | 1 | 300 | |
| P422 | No. 2 Pressure Response Sensitivity | 1 to 2000 | 1 | 200 | Table 6.7k |
| P423 | No. 3 Rise Time Gain | 0 to 9999 | 1 | 1500 | Table 6.7h |
| P424 | No. 3 Fall Time Gain | 0 to 9999 | 1 | 1500 | |
| P425 | No. 3 Lag Compensation | 1 to 2000 | 1 | 70 | Table 6.7i |
| P426 | No. 3 Lead Compensation | 1 to 2000 | 1 | 60 | |
| P427 | No. 3 Rise Time Pressure Command Filter | 1 to 2000 | 1 | 300 | Table 6.7j |
| P428 | No. 3 Fall Time Pressure Command Filter | 1 to 2000 | 1 | 300 | |
| P429 | No. 3 Pressure Response Sensitivity | 1 to 2000 | 1 | 200 | Table 6.7k |
| P430 | Manufacturer-controlled | - | - | 0 | - |
| P431 | Manufacturer-controlled | - | - | 0 | - |
| P432 | Manufacturer-controlled | - | - | 0 | - |
| P433 | Manufacturer-controlled | - | - | 0 | - |
| P434 | Manufacturer-controlled | - | - | 0 | - |
| P435 | Manufacturer-controlled | - | - | 0 | - |
| P436 | Manufacturer-controlled | - | - | 0 | - |
| P437 | Pressure Response Gain | 0 to 9999 | 1 | 300 | Table 6.7k |
| P438 | Pressure Response Offset | 0 to 9999 | 1 | 100 | |
| P439 | Pressure Proportional Gain | 0 to 9999 | 1 | 0 | Table 6.7l |
| P440 | Pressure Feedforward Gain | 0 to 9999 | 1 | 0 | |
| P441 | Pressure Feedforward Filter | 1 to 2000 | 1 | 1 | |
| P442 | Pressure Feedforward Function Selection | 0 to 3 | 1 | 0 | |
| P443 | Q-damping Gain | - 999 to 9999 | 1 | 0 | Table 6.7m |
| P444 | Q-damping Filter | 1 to 2000 | 1 | 1 | |
| P445 | Manufacturer-controlled | - | - | 0 | |
| P446 | Manufacturer-controlled | - | - | 0 | |
| P447 | Manufacturer-controlled | - | - | 0 | |

Table 6.6c Setting Parameters "P***"

| No. | Name | Setting Range | Minimum Setting Unit | Default | Reference |
|------|-------------------------------------|--|----------------------|------------------------|------------|
| P448 | Manufacturer-controlled | - | - | 45 | Table 6.7m |
| P449 | Number of Combined Units | 1 to 16 | 1 | 1 | |
| P450 | QIN Mini | 0 to 1000 | 1 (0.1 %) | 10 | |
| P451 | PIN Mini | 0 to 1000 | 1 (0.1 %) | 10 | Table 6.7n |
| P452 | Q-COMP | 0 to 2000 | 1 | 1000 | |
| P453 | Manufacturer-controlled | - | - | 0 | - |
| P454 | Flow Command Voltage (QIN) Span | 0 to 9999 | 1 (0.1 %) | (1000)* | Table 6.7o |
| P455 | Flow Command Voltage (QIN) Zero | - 999 to 9999 | 1mV | (0)* | |
| P456 | Pressure Command Voltage (PIN) Span | 0 to 9999 | 1 (0.1 %) | (1000)* | |
| P457 | Pressure Command Voltage (PIN) Zero | - 999 to 9999 | 1mV | (0)* | |
| P458 | Pressure Sensor Voltage Span | 0 to 9999 | 1 (0.1 %) | (1250)* | Table 6.7p |
| P459 | Pressure Sensor Voltage Zero | - 999 to 9999 | 1 mV | (500)* | |
| P460 | Rated Pressure | 1 to 300 | 1 (0.1 MPa) | 175 | |
| P461 | Rated Motor Speed | 1 to 2800 | 1 r/min | 2000 | Table 6.7q |
| P462 | Pressure Sensor Rated Value | 1 to 400 | 1 (0.1 MPa) | 350 | |
| P463 | AM Monitor Output Item Selection | 0 to 99 | 1 | 3 | - |
| P464 | Manufacturer-controlled | - | - | 0 | |
| P488 | Manufacturer-controlled | - | - | 120.0 | |
| P490 | Manufacturer-controlled | - | - | 15 | |
| P491 | Manufacturer-controlled | - | - | 30 | |
| P492 | Manufacturer-controlled | - | - | 100.0 | |
| P493 | Manufacturer-controlled | - | - | 45 | |
| P499 | Manufacturer-controlled | - | - | 0 | |
| P547 | Manufacturer-controlled | - | - | 0 | |
| P548 | Manufacturer-controlled | - | - | 9999 | |
| P800 | Manufacturer-controlled | - | - | 30 | |
| P818 | Manufacturer-controlled | - | - | 2 | |
| P819 | Manufacturer-controlled | - | - | 0 | |
| P820 | Manufacturer-controlled | - | - | (Depends on the model) | |
| P821 | Manufacturer-controlled | - | - | 0.050 | |
| P828 | Manufacturer-controlled | - | - | 150 | |
| P862 | Manufacturer-controlled | - | - | 0 | |
| P863 | Manufacturer-controlled | - | - | 0 | |
| P866 | Manufacturer-controlled | - | - | 200.0 | |
| P867 | Manufacturer-controlled | - | - | 0.01 | |
| P872 | Manufacturer-controlled | - | - | 1 | |
| P877 | Manufacturer-controlled | - | - | 2 | |
| P879 | Manufacturer-controlled | - | - | 150.0 | |
| P880 | Manufacturer-controlled | - | - | 0.3 | |
| P989 | Manufacturer-controlled | - | - | 10 | |
| P990 | Manufacturer-controlled | - | - | 1 | |
| P991 | Manufacturer-controlled | - | - | 58 | |
| C--- | Calibration Parameters | Pressing the "SET" button displays the parameters in "Table 6.6d." | | | |
| PrCL | Parameter Clear | 0, 1 | 1 | 0 | |
| ALLC | All Parameter Clear | 0, 1 | 1 | 0 | |
| ErCL | Manufacturer-controlled | - | - | 0 | |
| PCPY | Parameter Copy | 0, 1, 2, 3 | 1 | 0 | Table 6.7t |

*) Default values set by YUKEN. The values differ depending on the ASE model. The values in parentheses are reference values.

Table 6.7b Parameter Functions

| No. | Name | Function/Use | Default | Setting Range |
|------|---|--|-------------|--|
| P 52 | Operation Panel Display Data Selection | Selects a monitoring item to be displayed on the operation panel and a monitoring item to be output to the terminal FM. * See "Table 6.7b-1" below. | 0/ (100) | 0, 5 to 14, 17, 20, 23, 25, 55, 81 to 86, 100 |

Table 6.7b-1 Operation Panel Display Data Selection

| Monitoring Item | Setting Value | Unit | Description |
|--------------------------------|---------------|---------|---|
| Output Voltage | 0/100 | V | Output voltage supplied to the motor side. |
| Rotation Command | 5 | 1 r/min | Speed command. |
| Motor Speed | 6 | 1 r/min | Motor speed. |
| Motor Torque | 7 | 0.1 % | Torque value with the rated motor torque taken as 100 %. |
| Converter Output Voltage | 8 | 0.1 V | DC bus voltage value. |
| Dynamic Brake Utilization | 9 | 0.1 % | Rate of dynamic brake utilization set by the setting parameters "P_30" and "P_70." |
| Electronic Thermal Load Factor | 10 | 0.1 % | Accumulative value of motor thermal load with the electronic thermal triggering level taken as 100 %. |
| Output Current Peak | 11 | 0.1 A | Retains the peak value for output current monitoring (memory is reset every time the unit starts up). |
| Converter Output Voltage Peak | 12 | 0.1 V | Retains the peak value of DC bus voltage (memory is reset every time the unit starts up). |
| Input Voltage | 13 | 0.01 kW | Voltage on the AMSE controller input side. |
| Output Voltage | 14 | 0.01 kW | Voltage on the AMSE controller output side. |
| Load Meter | 17 | 0.1 % | Displays the torque current with the set value of "P_56" taken as 100 %. |
| Accumulative Power-on Time | 20 | 1 h | Accumulates the power-on time (0.001 = 1h: the value returns to 0 h after reaching 65,535 h (max.)). |
| Actual Operating Time | 23 | 1 h | Accumulates the operating time (0.001 = 1 h: the value returns to 0 h after reaching 65,535 h (max.)). |
| Accumulative Power Consumption | 25 | 0.01 kW | Displays the accumulative power consumption based on the monitored output voltage. |
| Input Terminal Status | 55 | - | Displays the "ON/OFF" status of the control circuit input terminals on the operation panel. See "Fig. 6.7a" below for display details. |
| Output Terminal Status | | - | Displays the "ON/OFF" status of the control circuit output terminals on the operation panel. See "Fig. 6.7a" below for display details. |
| Pressure Input Command | 81 | 0.01 V | Pressure command voltage. |
| Flow Input Command | 82 | 0.01 V | Flow command voltage. |
| AM Terminal Output | 83 | 0.01 V | Outputs an item selected by the setting parameter "P463." |
| Manufacturer-controlled | - | - | An output value is invalid. |
| Manufacturer-controlled | - | - | An output value is invalid. |
| Manufacturer-controlled | - | - | An output value is invalid. |




Fig. 6.7a Status of Input/Output Terminals

Table 6.7c Parameter Functions

| No. | Name | Function/Use | Default | Setting Range | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------|--|---|--------------------------------|--------------------------|-------------------------------|--------------------------------|---------|------------------|---|--|----------------------------|---|-------|-----------------|---|---------------------------|---|---|----|-----------------|---|---------------------------|----|---|----|-----------------|---|---------------------------|----|---|---|------------------|
| P 56 | Manufacturer-controlled | <p>* The setting value differs depending on the model.</p> <table border="1"> <thead> <tr> <th>Model</th> <th>Default</th> </tr> </thead> <tbody> <tr> <td>ASE3-4AA</td> <td>26.50</td> </tr> <tr> <td>ASE3-AA</td> <td>51.40</td> </tr> <tr> <td>ASE5-4BZ</td> <td>44.00</td> </tr> <tr> <td>ASE5-BZ</td> <td>84.00</td> </tr> <tr> <td>ASE10</td> <td>75.00</td> </tr> </tbody> </table> | Model | Default | ASE3-4AA | 26.50 | ASE3-AA | 51.40 | ASE5-4BZ | 44.00 | ASE5-BZ | 84.00 | ASE10 | 75.00 | See the table on the left. | 0 to 500 A | | | | | | | | | | | | | | | | |
| Model | Default | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE3-4AA | 26.50 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE3-AA | 51.40 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE5-4BZ | 44.00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE5-BZ | 84.00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE10 | 75.00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P 75 | Reset/ PU Disconnection/ PU Stop Selection | <p>Selects functions for reset input reception, operation panel connector disconnection (PU disconnection), and stop via the "STOP/RESET" button on the operation panel.</p> <table border="1"> <thead> <tr> <th>Setting Range</th> <th>Reset Function Selection</th> <th>Operation Panel Disconnection</th> <th>Stop via the STOP/RESET Button</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Always allowed.</td> <td rowspan="2">Operation continues when the operation panel is disconnected.</td> <td rowspan="2">"STOP" is disabled.</td> </tr> <tr> <td>1</td> <td>Allowed when the protection function is active.</td> </tr> <tr> <td>2</td> <td>Always allowed.</td> <td rowspan="2">Operation stops when the operation panel is disconnected.</td> <td rowspan="2">"STOP" is always enabled.</td> </tr> <tr> <td>3</td> <td>Allowed when the protection function is active.</td> </tr> <tr> <td>14</td> <td>Always allowed.</td> <td rowspan="2">Operation continues when the operation panel is disconnected.</td> <td rowspan="2">"STOP" is always enabled.</td> </tr> <tr> <td>15</td> <td>Allowed when the protection function is active.</td> </tr> <tr> <td>16</td> <td>Always allowed.</td> <td rowspan="2">Operation stops when the operation panel is disconnected.</td> <td rowspan="2">"STOP" is always enabled.</td> </tr> <tr> <td>17</td> <td>Allowed when the protection function is active.</td> </tr> </tbody> </table> | Setting Range | Reset Function Selection | Operation Panel Disconnection | Stop via the STOP/RESET Button | 0 | Always allowed. | Operation continues when the operation panel is disconnected. | "STOP" is disabled. | 1 | Allowed when the protection function is active. | 2 | Always allowed. | Operation stops when the operation panel is disconnected. | "STOP" is always enabled. | 3 | Allowed when the protection function is active. | 14 | Always allowed. | Operation continues when the operation panel is disconnected. | "STOP" is always enabled. | 15 | Allowed when the protection function is active. | 16 | Always allowed. | Operation stops when the operation panel is disconnected. | "STOP" is always enabled. | 17 | Allowed when the protection function is active. | 1 | 0 to 3, 14 to 17 |
| Setting Range | Reset Function Selection | Operation Panel Disconnection | Stop via the STOP/RESET Button | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Always allowed. | Operation continues when the operation panel is disconnected. | "STOP" is disabled. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Allowed when the protection function is active. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Always allowed. | Operation stops when the operation panel is disconnected. | "STOP" is always enabled. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Allowed when the protection function is active. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | Always allowed. | Operation continues when the operation panel is disconnected. | "STOP" is always enabled. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Allowed when the protection function is active. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 16 | Always allowed. | Operation stops when the operation panel is disconnected. | "STOP" is always enabled. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 17 | Allowed when the protection function is active. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P 77 | Parameter Write Selection | <p>Enables/disables write protection for parameters. This function can be used to prevent the parameters from being overwritten by mistake.</p> <table border="1"> <thead> <tr> <th>Setting Range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Writable only during stop.</td> </tr> <tr> <td>1</td> <td>Write-protected.</td> </tr> <tr> <td>2</td> <td>Writable regardless of the operation status.</td> </tr> </tbody> </table> | Setting Range | Description | 0 | Writable only during stop. | 1 | Write-protected. | 2 | Writable regardless of the operation status. | 2 | 0, 1, 2 | | | | | | | | | | | | | | | | | | | | |
| Setting Range | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Writable only during stop. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Write-protected. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Writable regardless of the operation status. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P 80 | Manufacturer-controlled | <p>* The setting value differs depending on the model.</p> <table border="1"> <thead> <tr> <th>Model</th> <th>Default</th> </tr> </thead> <tbody> <tr> <td>ASE3</td> <td>11.00</td> </tr> <tr> <td>ASE5</td> <td>20.00</td> </tr> <tr> <td>ASE10</td> <td>35.00</td> </tr> </tbody> </table> | Model | Default | ASE3 | 11.00 | ASE5 | 20.00 | ASE10 | 35.00 | See the table on the left. | 0.40 to 55.00 | | | | | | | | | | | | | | | | | | | | |
| Model | Default | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE3 | 11.00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE5 | 20.00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE10 | 35.00 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Table 6.7d Parameter Functions

| No. | Name | Function/Use | Default | Setting Range | | | | | | | | | | | | | |
|---------------|--|---|---------------|---------------|---|---|--|--|---|---------------------------------------|----|---|---------------------|----|---------------------------------------|----|--------------|
| P161 | Button Lock Operation Selection | <p>Enables/disables button operation on the operation panel. Enabling the "button lock mode" and pressing the "MODE" button on the operation panel for 2 seconds disables button operation.</p> <p>When button operation is disabled, "HOLD" is displayed on the operation panel.</p> <p>To enable button operation, press the "MODE" button for 2 seconds to cancel the button lock mode.</p> <table border="1"> <thead> <tr> <th>Setting Range</th> <th colspan="2">Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Puts the M dial into the motor speed setting mode.</td> <td rowspan="2">Button lock disabled</td> </tr> <tr> <td>1</td> <td>Puts the M dial into the volume mode.</td> </tr> <tr> <td>10</td> <td>Puts the M dial into the motor speed setting mode</td> <td rowspan="2">Button lock enabled</td> </tr> <tr> <td>11</td> <td>Puts the M dial into the volume mode.</td> </tr> </tbody> </table> | Setting Range | Description | | 0 | Puts the M dial into the motor speed setting mode. | Button lock disabled | 1 | Puts the M dial into the volume mode. | 10 | Puts the M dial into the motor speed setting mode | Button lock enabled | 11 | Puts the M dial into the volume mode. | 10 | 0, 1, 10, 11 |
| Setting Range | Description | | | | | | | | | | | | | | | | |
| 0 | Puts the M dial into the motor speed setting mode. | Button lock disabled | | | | | | | | | | | | | | | |
| 1 | Puts the M dial into the volume mode. | | | | | | | | | | | | | | | | |
| 10 | Puts the M dial into the motor speed setting mode | Button lock enabled | | | | | | | | | | | | | | | |
| 11 | Puts the M dial into the volume mode. | | | | | | | | | | | | | | | | |
| P244 | Cooling Fan Operation Selection | <p>Controls the operation of the cooling fan built in the inverter.</p> <table border="1"> <thead> <tr> <th>Setting Range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Starts the cooling fan when the power is turned "on." The fan stays "on" while the power is "on."</td> </tr> <tr> <td>1</td> <td>The cooling fan stays "on" during inverter operation. With the inverter stopped, the fan turns "on/off" according to the monitored inverter temperature.</td> </tr> </tbody> </table> | Setting Range | Description | 0 | Starts the cooling fan when the power is turned "on." The fan stays "on" while the power is "on." | 1 | The cooling fan stays "on" during inverter operation. With the inverter stopped, the fan turns "on/off" according to the monitored inverter temperature. | 1 | 0, 1 | | | | | | | |
| Setting Range | Description | | | | | | | | | | | | | | | | |
| 0 | Starts the cooling fan when the power is turned "on." The fan stays "on" while the power is "on." | | | | | | | | | | | | | | | | |
| 1 | The cooling fan stays "on" during inverter operation. With the inverter stopped, the fan turns "on/off" according to the monitored inverter temperature. | | | | | | | | | | | | | | | | |

Table 6.7e Parameter Functions

| No. | Name | Function/Use | Default | Setting Range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------|--|---|------------------------|---------------------------------|-------------|------------------------|---------------------------|---------|---|-------|--|---|-----------|---|---|----------|---|----|--------------------|-------------------------------------|---|-------|----|---|-------------------|---|---|----|---|---|---|---|----|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|-----|-----------|
| P255 | Life Warning Status Display | <p>If the inrush current limiting circuit, control circuit capacitor, or main circuit capacitor reaches the life expiration warning level, the parameter value is displayed as follows.</p> <table border="1"> <thead> <tr> <th>Display</th> <th>Inrush current limiting circuit</th> <th>Cooling fan</th> <th>Main circuit capacitor</th> <th>Control circuit capacitor</th> </tr> </thead> <tbody> <tr><td>15</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> <tr><td>14</td><td>○</td><td>○</td><td>○</td><td>×</td></tr> <tr><td>13</td><td>○</td><td>○</td><td>×</td><td>○</td></tr> <tr><td>12</td><td>○</td><td>○</td><td>×</td><td>×</td></tr> <tr><td>11</td><td>○</td><td>×</td><td>○</td><td>○</td></tr> <tr><td>10</td><td>○</td><td>×</td><td>○</td><td>×</td></tr> <tr><td>9</td><td>○</td><td>×</td><td>×</td><td>○</td></tr> <tr><td>8</td><td>○</td><td>×</td><td>×</td><td>×</td></tr> <tr><td>7</td><td>×</td><td>○</td><td>○</td><td>○</td></tr> <tr><td>6</td><td>×</td><td>○</td><td>○</td><td>×</td></tr> <tr><td>5</td><td>×</td><td>○</td><td>×</td><td>○</td></tr> <tr><td>4</td><td>×</td><td>○</td><td>×</td><td>×</td></tr> <tr><td>3</td><td>×</td><td>×</td><td>○</td><td>○</td></tr> <tr><td>2</td><td>×</td><td>×</td><td>○</td><td>×</td></tr> <tr><td>1</td><td>×</td><td>×</td><td>×</td><td>○</td></tr> <tr><td>0</td><td>×</td><td>×</td><td>×</td><td>×</td></tr> </tbody> </table> <p>* ○: With warning, ×: Without warning</p> | Display | Inrush current limiting circuit | Cooling fan | Main circuit capacitor | Control circuit capacitor | 15 | ○ | ○ | ○ | ○ | 14 | ○ | ○ | ○ | × | 13 | ○ | ○ | × | ○ | 12 | ○ | ○ | × | × | 11 | ○ | × | ○ | ○ | 10 | ○ | × | ○ | × | 9 | ○ | × | × | ○ | 8 | ○ | × | × | × | 7 | × | ○ | ○ | ○ | 6 | × | ○ | ○ | × | 5 | × | ○ | × | ○ | 4 | × | ○ | × | × | 3 | × | × | ○ | ○ | 2 | × | × | ○ | × | 1 | × | × | × | ○ | 0 | × | × | × | × | (0) | (0 to 15) |
| Display | Inrush current limiting circuit | Cooling fan | Main circuit capacitor | Control circuit capacitor | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | ○ | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | ○ | ○ | ○ | × | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | ○ | ○ | × | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | ○ | ○ | × | × | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | ○ | × | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | ○ | × | ○ | × | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | ○ | × | × | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | ○ | × | × | × | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | × | ○ | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | × | ○ | ○ | × | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | × | ○ | × | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | × | ○ | × | × | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | × | × | ○ | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | × | × | ○ | × | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | × | × | × | ○ | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | × | × | × | × | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P256 | Inrush Current Limiting Circuit Life Display | Counts the number of times of a contact (relay, contactor, or thyristor) turning "on" and performs a countdown from 100 % (1000,000 times) by 1 % per 10,000 times. When the count reaches 10 % (900,000), a life expiration warning is issued. | (100) | (0 to 100) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P257 | Control Circuit Capacitor Life Display | Calculates the remaining service life of the control circuit capacitor based on the power-on time and humidity and performs a countdown from 100 %. When the count falls below 10 %, a life expiration warning is issued. | (100) | (0 to 100) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P258 | Main Circuit Capacitor Life Display | Issues a life expiration warning when the measured capacity of the main circuit capacitor falls below 85 %, with the default capacity level taken as 100 %. * The measurement is not performed automatically. The measurement must be performed by using P259. | (100) | (0 to 100) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P259 | Main Circuit Capacitor Life Measurement | <p>Measures the capacity of the main circuit capacitor as follows.</p> <ol style="list-style-type: none"> Connect the motor and place the unit in the emergency stop state. Set "P259" to "1." Power "off" the AMSE controller. In 5 seconds, power it "on." After checking that P259 indicates "3" (Complete), read the measured value by using P258. <table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Remark</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>None</td> <td>Default</td> </tr> <tr> <td>1</td> <td>Start</td> <td>Measurement starts when the power is turned "off."</td> </tr> <tr> <td>2</td> <td>Measuring</td> <td></td> </tr> <tr> <td>3</td> <td>Complete</td> <td></td> </tr> <tr> <td>8</td> <td>Forced Termination</td> <td>Issued when the wiring is improper.</td> </tr> <tr> <td>9</td> <td>Error</td> <td></td> </tr> </tbody> </table> | Display | Description | Remark | 0 | None | Default | 1 | Start | Measurement starts when the power is turned "off." | 2 | Measuring | | 3 | Complete | | 8 | Forced Termination | Issued when the wiring is improper. | 9 | Error | | 0 | 0, 1 (2, 3, 8, 9) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display | Description | Remark | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | None | Default | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Start | Measurement starts when the power is turned "off." | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Measuring | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Complete | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Forced Termination | Issued when the wiring is improper. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Table 6.7h Parameter Functions

| No. | Name | Function/Use | Default | Setting Range |
|------|-------------------------|--|---------|---------------|
| P402 | No. 0 Rise Time Gain | <p>Sets the pressure control gain at the pressure rise time. Increasing the setting value improves the response, but an excessively high value may result in vibrations.</p> | 1500 | 0 to 9999 |
| P409 | No. 1 Rise Time Gain | | | |
| P416 | No. 2 Rise Time Gain | | | |
| P423 | No. 3 Rise Time Gain | | | |
| P403 | No. 0 Fall Time Gain | <p>Sets the pressure control gain at the pressure fall time. Increasing the setting value improves the response, but an excessively high value may result in vibrations.</p> | 1500 | 0 to 9999 |
| P410 | No. 1 Fall Time Gain | | | |
| P417 | No. 2 Fall Time Gain | | | |
| P424 | No. 3 Fall Time Gain | | | |

Table 6.7i Parameter Functions

| No. | Name | Function/Use | Default | Setting Range |
|------|----------------------------|--|---------|---------------|
| P404 | No. 0 Lag Compensation | <p>Sets the pressure control lag time constant.</p> <p>Lag compensation is used when the control gain cannot be increased, and the operation is not stabilized. It can prevent oscillations in a frequency band of several Hz. Excessively increasing the value deteriorates the response and overshoot characteristics; it is recommended to adjust it in combination with lead compensation.</p> | 70 | 1 to 2000 |
| P411 | No. 1 Lag Compensation | | | |
| P418 | No. 2 Lag Compensation | | | |
| P425 | No. 3 Lag Compensation | | | |
| P405 | No. 0 Lead Compensation | <p>Sets the pressure control lead time constant.</p> <p>Lead compensation is used to improve the damping characteristics by preventing overshooting.</p> <p>Excessively increasing the value may result in oscillations in a high frequency band.</p> | 60 | 1 to 2000 |
| P412 | No. 1 Lead Compensation | | | |
| P419 | No. 2 Lead Compensation | | | |
| P426 | No. 3 Lead Compensation | | | |

Table 6.7j Parameter Functions



| No. | Name | Function/Use | Default | Setting Range |
|------|---|--|---------|---------------|
| P406 | No. 0 Rise Time Pressure Command Filter | <p>Sets the first-order lag filter for pressure command input. It can be set at the pressure rise time. It prevents overshooting in the case of stepped changes in pressure command voltage.</p>  | 300 | 1 to 2000 |
| P413 | No. 1 Rise Time Pressure Command Filter | | | |
| P420 | No. 2 Rise Time Pressure Command Filter | | | |
| P427 | No. 3 Rise Time Pressure Command Filter | | | |
| P407 | No. 0 Fall Time Pressure Command Filter | <p>Sets the first-order lag filter for pressure command input. It can be set at the pressure fall time. It prevents undershooting in the case of stepped changes in pressure command voltage.</p>  | 300 | 1 to 2000 |
| P414 | No. 1 Fall Time Pressure Command Filter | | | |
| P421 | No. 2 Fall Time Pressure Command Filter | | | |
| P428 | No. 3 Fall Time Pressure Command Filter | | | |

Table 6.7k Parameter Functions



| No. | Name | Function/Use | Default | Setting Range |
|------|--|--|---------|---------------|
| P408 | No. 0 Pressure Response Sensitivity | <p>Sets the pressure response sensitivity for switching from flow control to pressure control. Increasing the value reduces the surge upon switching to pressure control but deteriorates the override characteristics.</p>  | 200 | 1 to 2000 |
| P415 | No. 1 Pressure Response Sensitivity | | | |
| P422 | No. 2 Pressure Response Sensitivity | | | |
| P429 | No. 3 Pressure Response Sensitivity | | | |
| P437 | Pressure Response Gain | Sets the pressure response gain for the above deviation. | 300 | 0 to 9999 |
| P438 | Pressure Response Offset | <p>Sets the pressure deviation for switching from flow control to pressure control. The timing of switching from flow control to pressure control is changed to reduce the surge pressure. Note that the parameter also affects the override characteristics.</p>  | 100 | 0 to 9999 |

Table 6.71 Parameter Functions




| No. | Name | Function/Use | Default | Setting Range |
|------|---|--|---------|---------------|
| P439 | Pressure Proportional Gain | This proportional gain is independent of control compensation, unlike the rise or fall time gain. It improves the response and minimizes disturbance. Since the response is not regulated by control compensation, an excessively high value may result in oscillations. | 0 | 0 to 9999 |
| P440 | Pressure Feedforward Gain | Performs the feedforward control of changes in pressure command voltage (derivative) to improve the pressure wave response. | 0 | 0 to 9999 |
| P441 | Pressure Feedforward Filter | | 1 | 1 to 2000 |
| P442 | Pressure Feedforward Function Selection | <p>- Feedforward Gain: Sets the sensitivity added to pressure control in relation to the change described above.</p> <p>- Feedforward Filter: Filters the return of feedforward signals to keep the function effective against sudden changes.</p> <p>- Feedforward Function Selection: Selects the method of adding feedforward signals. 0: Adding to pressure control at both the pressure rise and fall times. 1: Adding to pressure control at the pressure rise time only. 2: Adding to flow control at both the pressure rise and fall times. 3: Adding to flow control at the pressure rise time only.</p>  | 0 | 0, 1, 2, 3 |

Table 6.7m Parameter Functions

| No. | Name | Function/Use | Default | Setting Range |
|------|--------------------------|--|---------|-------------------|
| P443 | Q-damping Gain | <p>Detects the motor speed during pressure control and adds its derivative to pressure control.</p> <p>This function is effective when the pressure trackability is not good due to a large compression volume on the load side.</p> <ul style="list-style-type: none"> - Q-damping Gain: Sets the sensitivity added to pressure control in relation to the change described above. - Q-damping Filter: Filters the return of Q-damping control signals to keep the function effective against sudden changes. | 0 | - 999 to 9999 |
| P444 | Q-damping filter | | 1 | 1 to 2000 |
| P449 | Number of Combined Units | <p>Inputs the required number of units for combination use.</p> <p>Sets the lower limit of the motor speed in relation to flow (motor speed) command voltage.</p> | 1 | 1 to 16 |
| P450 | QIN Mini | <p>It prevents reverse rotation of the pump due to command voltage variations caused by noise or due to improper operation/input.</p> <p>e.g.) If the parameter is set to 10 (1.0 %) with a rated motor speed of 2000 rpm, the minimum motor speed is 20 rpm.</p> | 10 | 0 to 1000 × 0.1 % |

Table 6.7o Parameter Functions

| No. | Name | Function/Use | Default | Setting Range |
|------|-------------------------------|---|---------|-----------------------|
| P454 | Flow Command Voltage Span | Adjusts the span of flow (motor speed) command voltage. This parameter provides the variable control of pump motor speed in relation to command voltage. At the default value, or 1000 (100.0 %), the rated motor speed is achieved with the input of a command voltage of 5 V. | 1000 | 0 to 9999 × 0.1 % |
| P455 | Flow Command Voltage Zero | The zero point of command voltage is adjusted by "P455." e.g.) When the command at the output side is zero and the terminal block voltage (between 4 and 5) is 50 mv, input +50.  | 0 | - 999 to 9999 × 0.1 % |
| P456 | Pressure Command Voltage Span | Adjusts the span of pressure command voltage. This parameter provides the variable control of pressure in relation to command voltage. At the default value, or 1000 (100.0 %), the rated pressure is achieved with the input of a command voltage of 5 V. | 1000 | 0 to 9999 × 0.1 % |
| P457 | Pressure Command Voltage Zero | The zero point of command voltage is adjusted by "P457." e.g.) When the command at the output side is zero and the terminal block voltage (between 2 and 5) is 50 mv, input +50.  | 0 | - 999 to 9999 × 0.1 % |

MEMO

Table 6.7p Parameter Functions

| No. | Name | Function/Use | Default | Setting Range | | | | | | | | | | | | | | | |
|--------------------------------|----------------------|--|--------------------------------|----------------------|----------------------|--------------|------|------|--------------|-----|------|----------|---|------|----------|------|------|-----|------------------|
| P458 | Pressure Sensor Span | Adjusts the zero point/span of pressure sensor input voltage. | 1250 | 0 to 9999 × 0.1 % | | | | | | | | | | | | | | | |
| P459 | Pressure Sensor Zero | <p>Adjusts the zero point/span of pressure sensor input voltage. According to the output voltage specification of the pressure sensor, set the parameters as follows.</p> <table border="1"> <thead> <tr> <th>Pressure Sensor Output Voltage</th> <th>Pressure Sensor Zero</th> <th>Pressure Sensor Span</th> </tr> </thead> <tbody> <tr> <td>0.5 to 4.5 V</td> <td>P459</td> <td>P458</td> </tr> <tr> <td>0.5 to 4.5 V</td> <td>500</td> <td>1250</td> </tr> <tr> <td>0 to 5 V</td> <td>0</td> <td>1000</td> </tr> <tr> <td>1 to 5 V</td> <td>1000</td> <td>1250</td> </tr> </tbody> </table> <p>* By default, the values for 0.5 to 4.5 V are set.</p> | Pressure Sensor Output Voltage | Pressure Sensor Zero | Pressure Sensor Span | 0.5 to 4.5 V | P459 | P458 | 0.5 to 4.5 V | 500 | 1250 | 0 to 5 V | 0 | 1000 | 1 to 5 V | 1000 | 1250 | 500 | - 999 to 9999 Mv |
| Pressure Sensor Output Voltage | Pressure Sensor Zero | Pressure Sensor Span | | | | | | | | | | | | | | | | | |
| 0.5 to 4.5 V | P459 | P458 | | | | | | | | | | | | | | | | | |
| 0.5 to 4.5 V | 500 | 1250 | | | | | | | | | | | | | | | | | |
| 0 to 5 V | 0 | 1000 | | | | | | | | | | | | | | | | | |
| 1 to 5 V | 1000 | 1250 | | | | | | | | | | | | | | | | | |
| P460 | Rated Pressure | <p>Sets the pressure at a pressure command voltage of DC + 5 V. This parameter is used to change the rated pressure without changing the pressure command voltage. When pressure monitoring (SMP) is selected for AM monitoring output, the set pressure is output at DC + 5 V.</p> | 175 | 1 to 300 × 0.1 MPa | | | | | | | | | | | | | | | |
| P461 | Rated Motor Speed | <p>Sets the motor speed at a flow command voltage of DC + 5 V. This parameter is used to change the rated motor speed without changing the flow command voltage. When motor speed monitoring (SMN) is selected for AM monitoring output, the set motor speed is output at DC + 5 V.</p> | 2000 | 1 to 3000 r/min | | | | | | | | | | | | | | | |

Table 6.7q Parameter Functions


| No. | Name | Function/Use | Default | Setting Range | | | | | | | | | | | | | | | | | | | | | | | | |
|----------|-------------------------------------|---|--|--|----------|----|---------------------|--|----------|------------------|---|----|--------------|--|----------------------------|-------------------------|--|---|--|--|---|--------|-----------------|---|-------------|-----------------|--|--|
| P462 | Pressure Sensor Rated Value | <p>Sets the rated pressure for the pressure sensor.</p> <p>The rated output of the pressure sensor for the ASE pump system is obtained at DC 0.5 to 4.5 V/0 to 35 MPa. Thus, the rated value is 350 (35.0 MPa).</p>  | 350 | 1 to 400 × 0.1 MPa | | | | | | | | | | | | | | | | | | | | | | | | |
| P463 | AM Monitoring Output Item Selection | Parameter Selection Items | 3 | 0 to 99 | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Setting Value</th> <th>Name</th> <th>Code</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Motor Speed Command</td> <td>2.5±2.5V / 0 ± Rated Motor Speed(Set Value P461)</td> </tr> <tr> <td>1</td> <td>Pressure Command</td> <td>2.5-5V / 0 -Command Voltage at Rated Pressure</td> </tr> <tr> <td>2</td> <td>Flow Command</td> <td>2.5-5V / 0 -Command Voltage at Rated Motor Speed</td> </tr> <tr> <td>3</td> <td>Pressure Sensor Monitor</td> <td>2.5±2.5V / 0 ±Rated Pressure(Set Value P462)</td> </tr> <tr> <td>4</td> <td>Motor Speed Monitor (Calculated Value)</td> <td>2.5±2.5V / 0 ± Rated Motor Speed(Set Value P461)</td> </tr> <tr> <td>5</td> <td>Torque</td> <td>2.5-5V / 0-250%</td> </tr> <tr> <td>6</td> <td>Load Factor</td> <td>2.5-5V / 0-250%</td> </tr> </tbody> </table> | Setting Value | Name | Code | 0 | Motor Speed Command | 2.5±2.5V / 0 ± Rated Motor Speed(Set Value P461) | 1 | Pressure Command | 2.5-5V / 0 -Command Voltage at Rated Pressure | 2 | Flow Command | 2.5-5V / 0 -Command Voltage at Rated Motor Speed | 3 | Pressure Sensor Monitor | 2.5±2.5V / 0 ±Rated Pressure(Set Value P462) | 4 | Motor Speed Monitor (Calculated Value) | 2.5±2.5V / 0 ± Rated Motor Speed(Set Value P461) | 5 | Torque | 2.5-5V / 0-250% | 6 | Load Factor | 2.5-5V / 0-250% | | |
| | | Setting Value | Name | Code | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 | Motor Speed Command | 2.5±2.5V / 0 ± Rated Motor Speed(Set Value P461) | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 1 | Pressure Command | 2.5-5V / 0 -Command Voltage at Rated Pressure | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 2 | Flow Command | 2.5-5V / 0 -Command Voltage at Rated Motor Speed | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 3 | Pressure Sensor Monitor | 2.5±2.5V / 0 ±Rated Pressure(Set Value P462) | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 4 | Motor Speed Monitor (Calculated Value) | 2.5±2.5V / 0 ± Rated Motor Speed(Set Value P461) | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Torque | 2.5-5V / 0-250% | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Load Factor | 2.5-5V / 0-250% | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| P820 | Manufacturer-controlled | <p>* The setting value varies depending on the models.</p> <table border="1"> <thead> <tr> <th>Model</th> <th>Default</th> </tr> </thead> <tbody> <tr> <td>ASE3-4AA</td> <td>60</td> </tr> <tr> <td>ASE3- AA</td> <td>60</td> </tr> <tr> <td>ASE5-4BZ</td> <td>60</td> </tr> <tr> <td>ASE5- BZ</td> <td>40</td> </tr> <tr> <td>ASE10</td> <td>60</td> </tr> </tbody> </table> | Model | Default | ASE3-4AA | 60 | ASE3- AA | 60 | ASE5-4BZ | 60 | ASE5- BZ | 40 | ASE10 | 60 | See the table on the left. | - | | | | | | | | | | | | |
| Model | Default | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE3-4AA | 60 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE3- AA | 60 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE5-4BZ | 60 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE5- BZ | 40 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ASE10 | 60 | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Table 6.7s Parameter Functions

| No. | Name | Function/Use | Default | Setting Range | | | | | | |
|---------------|---------------------------|--|---------------|---------------|---|----------------|---|---------------------------|---|------|
| C___ | Calibration Parameters | Automatically calibrates the input/output of each terminal. * See "Table 6.7v" for details. | - | - | | | | | | |
| PrCL | Parameter Clear | <p>Initializes a parameter. * Calibration parameters are not initialized. * Parameters are not initialized when "P_77" is set to "1."</p> <table border="1"> <thead> <tr> <th>Setting Range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not initialize</td> </tr> <tr> <td>1</td> <td>Initialize</td> </tr> </tbody> </table> | Setting Range | Description | 0 | Not initialize | 1 | Initialize | 0 | 0, 1 |
| Setting Range | Description | | | | | | | | | |
| 0 | Not initialize | | | | | | | | | |
| 1 | Initialize | | | | | | | | | |
| ALLC | All Parameter Clear | <p><Do not use this parameter unless under special circumstances.> Initializes all parameters. * Parameters are not initialized when "P_77" is set to "1."</p> <table border="1"> <thead> <tr> <th>Setting Range</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not initialize</td> </tr> <tr> <td>1</td> <td>Initialize all parameters</td> </tr> </tbody> </table> | Setting Range | Description | 0 | Not initialize | 1 | Initialize all parameters | 0 | 0, 1 |
| Setting Range | Description | | | | | | | | | |
| 0 | Not initialize | | | | | | | | | |
| 1 | Initialize all parameters | | | | | | | | | |
| Ercl | Manufacturer-controlled | Protected. | 0 | - | | | | | | |

Table 6.7t Parameter Functions

| No. | Name | Function/Use | Default | Setting Range | | | | | | | | | | |
|---------------|---|---|---------------|---------------|---|---------|---|--|---|--|---|---|---|------------|
| PCPY | Parameter Copy | <p>Copies setting parameter data when using multiple AMSE controllers.</p> <table border="1" data-bbox="544 412 1139 665"> <thead> <tr> <th data-bbox="544 412 667 450">Setting Range</th> <th data-bbox="671 412 1139 450">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="544 456 667 486">0</td> <td data-bbox="671 456 1139 486">Cancel.</td> </tr> <tr> <td data-bbox="544 492 667 521">1</td> <td data-bbox="671 492 1139 521">Copies the original data of parameters to the operation panel.</td> </tr> <tr> <td data-bbox="544 528 667 557">2</td> <td data-bbox="671 528 1139 557">Writes the copied setting parameter data to the destination AMSE controller.</td> </tr> <tr> <td data-bbox="544 564 667 593">3</td> <td data-bbox="671 564 1139 593">Cross checks the setting parameter data written to the destination AMSE controller against the data on the operation panel.</td> </tr> </tbody> </table> <p>Setting method Note) Do not perform this work during operation.</p> <p>1) Copy the original data of setting parameters to the operation panel. 1. Display the setting parameter "PCPY" and press the "SET" button. 2. Turn the "M Dial" to change from "0: Default" to "1." 3. Then, press the "SET" button. After the display flickers for about 30 seconds, "PCPY" appears to indicate the completion of the copy.</p> <p>2) Write the copied setting parameter data to the destination AMSE controller. 1. Connect the operation panel to the destination AMSE controller and power on the operation panel. 2. Display the setting parameter "PCPY" and press the "SET" button. 3. Turn the "M Dial" to change to "2." 4. Then, press the "SET" button. After the display flickers for about 30 seconds, "PCPY" appears to indicate the completion of the write. 5. For the setting parameters to take effect, power "off" and then on the AMSE controller.</p> <p>3) Cross check the setting parameter data. 1. Connect the operation panel retaining the setting parameter data to the destination AMSE controller and power on the operation panel. 2. Display the setting parameter "PCPY" and press the "SET" button. 3. Turn the "M Dial" to change to "3." 4. Then, press the "SET" button. The setting parameter data is loaded from the destination AMSE controller in about 30 seconds. 5. If any difference is found, the related setting parameter No. and "rE_3" are displayed alternately.</p> <p>Every time the "SET" button is pressed, the parameter No. and setting value are displayed alternately from one parameter in question to another. When all parameters in question are corrected, "3" is displayed. * If there is no parameter in question, "PCPY" and "3" are displayed alternately.</p> | Setting Range | Description | 0 | Cancel. | 1 | Copies the original data of parameters to the operation panel. | 2 | Writes the copied setting parameter data to the destination AMSE controller. | 3 | Cross checks the setting parameter data written to the destination AMSE controller against the data on the operation panel. | 0 | 0, 1, 2, 3 |
| Setting Range | Description | | | | | | | | | | | | | |
| 0 | Cancel. | | | | | | | | | | | | | |
| 1 | Copies the original data of parameters to the operation panel. | | | | | | | | | | | | | |
| 2 | Writes the copied setting parameter data to the destination AMSE controller. | | | | | | | | | | | | | |
| 3 | Cross checks the setting parameter data written to the destination AMSE controller against the data on the operation panel. | | | | | | | | | | | | | |

7. Troubleshooting

7.1 Error indication

The ASE pump unit can issue “alarms” that are generated with the detection of system errors and stop system operation, “warnings” that are generated with the detection of system errors but allow continued system operation, and “error messages” generated by improper operation.

The monitor of the operation panel indicates a code for each error. The user can identify the error cause by referring to this manual.

7.1.1 Alarms

An alarm is displayed when significant failure occurs to the ASE pump unit. Take appropriate measures in the event of an alarm. Any alarm shuts off the output and stops system operation, while the AMSE controller outputs an alarm signal.


The operation panel displays the code for the alarm (see Table 7.1a below).

Reset the alarm after removing the error cause and then restart system operation.

Note) Alarms are output via relay contacts. For details, see “Table 2.7c: Alarm Output.”

Note) Alarm codes are output via the open collector. For details, see “Table 2.7d: Sequence Output.”

Table 7.1a Alarm Codes

| Alarm | Alarm Code | | | Name | Reference | Alarm Reset | | | | |
|-------|-----------------------------|-----|-----|---|---|--|-----|----|----------------------------------|------------|
| | FU | SU | IPF | | | | | | | |
| E. PE | OFF | OFF | OFF | Parameter Memory Device Error | Table 7.2a | 1) To reset an alarm, press  on the operation panel. 2) Turn “off” and the on the power. 3) Turn “on” RES (Reset Signal) for at least 0.1 second. Note) For details, see “Table 2.7a: Sequence Input.” | | | | |
| E. 6 | | | | CPU Error | | | | | | |
| E. 7 | | | | Inrush Current Limiting Circuit Error | | | | | | |
| E.CPU | | | | Analog Input Error | | | | | | |
| E.IOH | | | | Option Error | | | | | | |
| E.AIE | | | | Communication Error | | | | | | |
| E.OPF | | | | Internal Circuit Error | | | | | | |
| E.SEr | | | | DC 24 Power Output Short Circuit | | | | | | |
| E. 13 | | | | Operation Panel Power Short Circuit | | | | | | |
| E.P24 | | | | USB Communication Error | | | | | | |
| E.CfE | | | | Hydraulic Control Board Error | | | | | | |
| E.USB | | | | Hydraulic Control Board Communication Error | | | | | | |
| E.OP3 | | | | OFF | | | OFF | ON | Regeneration Overvoltage | Table 7.2b |
| E. 3 | | | | | | | | | Brake Transistor Error Detection | |
| E.Ov3 | Undervoltage | | | | | | | | | |
| E_bE | Instantaneous Power Failure | | | | | | | | | |
| E.UuΓ | AMSE Controller Overload | | | | | | | | | |
| E.IPF | Motor Overload | | | | | | | | | |
| E.ΓHΓ | Fin Overheat | | | | | | | | | |
| E.ΓHΠ | Stall Prevention | | | | | | | | | |
| E.FIn | Overcurrent | | | | | | | | | |
| E.OLΓ | ON | OFF | OFF | | Ground Fault Overcurrent on the Output Side | Table 7.2c | | | | |
| E.OC3 | | | | Input Phase Failure | | | | | | |
| E. GF | | | | Output Phase Failure | | | | | | |
| E.ILF | | | | PU Disconnection | | | | | | |
| E.LF | | | | | | | | | | |
| E.PUE | | | | | | | | | | |

Note 1) After removing the error cause, wait about 30 minutes until the unit cools down.

7.1.2 Warnings

When the probability of the failure of the ASE pump unit is determined, warnings are displayed before alarm output.

Take appropriate measures in the event of a warning. While the system continues operation, the AMSE controller outputs a warning signal, and the operation panel displays the code for the warning.

When any warning is output, take measures to prevent the occurrence of serious failure.

Table 7.1b Warnings

| Warning | Name | Reference |
|---------|---------------------------------|------------|
| OL | Stall Prevention (Overcurrent) | Table 7.2d |
| Rb | Dynamic Brake Pre-alarm | |
| ГH | Electronic Thermal Pre-alarm | |
| PS | PU Stop | |
| CP | Parameter Copy | |
| Fn | Fan Fault | |
| oP | Hydraulic Control Board Warning | |

Note) Contact us when other warning codes are displayed.

7.1.3 Error messages

In the event of setting failure due to improper operation, an error code is displayed on the operation panel.

Set the relevant parameter properly by referring to this manual.

Table 7.1c Error Messages

| Error Message | Name | Reference |
|---------------|---------------------------|------------|
| HOLD | Operation Panel Lock | Table 7.2e |
| Er 1 | Parameter Write Error - 1 | |
| Er 2 | Parameter Write Error - 2 | |
| Er 3 | Parameter Write Error - 3 | |
| Er 4 | Parameter Write Error - 4 | |
| rE 1 | Copy Operation Error - 1 | |
| rE 2 | Copy Operation Error - 2 | |
| rE 3 | Copy Operation Error - 3 | |
| rE 4 | Copy Operation Error - 4 | |
| Err | Error | |

7.1.4 Status display

During operation, the operation status code is displayed on the operation panel.

Table 7.1d Status Display

| Status | Name | Reference |
|--------|----------------|------------|
| EПG | Emergency Stop | Table 7.2f |

7.2 Measures against alarms (error indication)

**CAUTION**

- ◆ When an alarm occurs, remove its cause and ensure safety. Then, reset the alarm and restart system operation.
- ◆ When an alarm occurs, immediately turn “off” STF (Serve-on) and shut off the power supply.
- ◆ If any of the following alarms occurs, do not restart operation by resetting the alarm. Doing so may cause failure of the servo amplifier or motor. In such cases, remove the alarm cause and wait 30 minutes or more until the unit cools down. Then, restart operation:
 - E.IOH, □E.ΓHF, or □E.ΓHP.

An alarm can be reset by powering **off** and then **on** the unit, pressing the “STOP/RESET” button on the operation panel, or turning **on** RES (Reset).

Table 7.2a Measures Against Alarms

| Alarm | Name | Description | Cause | Remedy |
|-------|---------------------------------------|--|--|--|
| E. PE | Parameter Memory Device Error | EEPROM failure (control board). | Excessive parameter write operations. | - Replace the AMSE controller |
| E. 6 | CPU Error | Communication error of the built-in CPU. | Noise. | - Take measures against devices producing excessive noise near the AMSE controller. |
| E. 7 | | | | |
| E.CPU | | | | |
| E.IOH | Inrush Current Limiting Circuit Error | The resistor of the inrush current limiting circuit has overheated. | Repeated power-on/off cycles. | Replace the circuit with the one that does not perform frequent power-on/off cycles. |
| E.AIE | Analog Input Error | Input of 30 mA or more or voltage input after changing the control circuit terminals “2” and “4” to the settings for current command specifications. | Change of the setting of the voltage/current switch. | Correct the setting of the voltage/current switch. |
| E.OPF | Option Error | Communication circuit error of a communication option. | Failure of the hydraulic control board connector. | Check the connection of the hydraulic control board. |
| | | | Communication error due to a parameter setting change. | Initialize the setting parameter. |
| E.SEr | Communication Error | RS-485 communication error | The number of communication errors has exceeded the allowable threshold set by the setting parameter “335: RS-485 Communication Retry Count” (excluding “9999”). The communication downtime is longer than the threshold set by the setting parameter “336: RS-485 Communication Check Time Interval.” | <ul style="list-style-type: none"> - Set the parameter with sufficient margin. - Modify the wiring to ensure the availability of RS-485 communication. |
| E. 13 | Internal Circuit Error | Internal circuit error. | Failure. | Contact the place of purchase. |
| E.P24 | DC 24 Power Output Short Circuit | Short circuit of DC 24 V power supplied from the control circuit terminal “PC.” | Short circuit of the PC terminal. | Disconnect the wire from the PC terminal to check whether the error can be removed. Then, check whether the wire connected to the PC terminal is short-circuited. |

Table 7.2b Measures Against Alarms

| Alarm | Name | Description | Cause | Remedy |
|-------|---|---|--|---|
| E.CFE | Operation Panel Power Short Circuit RS-485 Terminal Power Short Circuit | Short circuit of the operation panel power (PU connector). Short circuit of the RS-485 terminal power. | Short circuit of the power cable of each power supply. | Check the short-circuited part. Replace the operation panel. |
| E.USb | USB Communication Error | Interruption of USB communication. | Contact failure. | Check the cable. |
| E.OP3 | Hydraulic Control Board Error | Pressure sensor output error. EEPROM error. | Disconnection of the pressure sensor. EEPROM read error. | Check the wiring. Replace the wiring. Replace the pressure sensor. |
| E. 3 | Hydraulic Control Board Communication Error | Interruption of communication between the hydraulic control board and the driver. | Contact failure of the connector. Board failure. | Replace the AMSE controller. |
| E.Ov3 | Regenerative overvoltage | Regeneration during deceleration/stop. Overvoltage shutdown. | Rapid deceleration. | Increase the deceleration time. Reduce the braking frequency. Use a brake unit/power regenerative converter, if required. |
| E.bE | Brake Transistor Error Detection | Damage to the brake transistor or brake circuit failure. | A large volume of released pressure. High braking frequency (the cycle time must be set with sufficient margin). | The replacement of the AMSE controller is required. |
| E.UuF | Undervoltage | The primary power voltage applied to "R/L1," "S/L2," and "T/L3" of the main circuit terminal block is 300 V or less. The short bar between "P/+" and "P1" of the main circuit terminal block or DC reactor is connected. | Low power voltage. Any factor that reduces the main power voltage and causes the error (startup of a large-size motor, etc.). | Check the power facilities. If a DC reactor is in use, check the wiring. |
| E.IPF | Instantaneous Power Failure | Power failure lasting more than 15 ms. *1: This error is not output in the case of a power failure of more than 100 ms. *2: The operation continues in the event of an instantaneous power failure of 15 ms or less. | Interruption of power supply for more than 15 ms but less than 100 ms. | Remove the cause of instantaneous power failure. Prepare a backup power supply for instantaneous power failure. |
| E.ГНГ | AMSE Controller Overload Shutdown | When the rated output current is exceeded and if overcurrent shutdown does not occur, the electronic thermal with inverse time characteristics is activated for output transistor protection. | The motor's rated load factor has been exceeded. | Reduce the load. - Reduce the pressure setting. - Reduce the cycle load by operating the system at intervals. |
| E.ГНП | Motor Overload Shutdown | The electronic thermal in the AMSE controller has detected a motor overheat caused by overload or reduced cooling capability during constant speed operation. | High overload factor of the motor. The set value of the setting parameter "71: Applicable Motor" is improper. | Modify the motor environment (ambient temperature). Check that the motor fan works normally. |

Table 7.2c Measures Against Alarms

| Alarm | Name | Description | Cause | Remedy |
|-------|---|---|---|--|
| E.FIn | Fin Overheat | The cooling fin of the AMSE controller has overheated. | 1) Ambient temperature around the AMSE controller is high. 2) The cooling fin has been clogged. 3) The cooling fan has stopped. | 1) Check that the ambient temperature is as specified. 2) Clean the cooling fin. 3) Replace the cooling fan. |
| E.OLF | Stall Prevention | The operation has been stopped by the torque limiting function. | Overload. | Reduce the load. |
| E.OC3 | Overcurrent | The current level has exceeded the specified current value. | Operation at zero rotation. | Avoid operating at near-zero rotation. |
| | | | Rapid deceleration. | Increase the deceleration time. |
| | | | Output short circuit. | Check the wiring. |
| E._GF | Ground Fault Overcurrent on the Output Side | A ground fault has occurred on the output side of the AMSE controller. | | Restore the section where the ground fault has occurred. |
| E.ILF | Input Open-phase | One of the three input power phases has opened. | Disconnection of the 3-phase power cable. | Check the wiring. |
| E.PUE | PU Disconnection | Interruption of communication between the operation panel and the PU terminals. | Disconnection of the operation panel. Setting of the setting parameter "P_75: Reset" at "2," "3," "16," or "17." | Reset "P_75" to "0," "1," "14," or "15" so that the operation continues when the operation panel is disconnected. |

Table 7.2d Measures Against Warnings

| Alarm | Name | Description | Cause | Remedy |
|-------|---------------------------------|--|--|---|
| OL | Stall Prevention (Overcurrent) | The threshold set by the setting parameter "P_22: Stall Prevention Operation Level" has been exceeded. | The load is too high. | Reduce the load. Increase the settings of "P_7: Acceleration Time" and "P_8: Deceleration Time." Check that the setting parameter "P_13" has been set to "0." |
| rb | Dynamic Brake Pre-alarm | The dynamic brake utilization has exceeded 85 % of the set value. | The frequency of the dynamic brake utilization is high. | Increase the setting of "P_8: Deceleration Time" (extend the deceleration time). |
| ΓH | Electronic Thermal Pre-alarm | The value has exceeded 85 % of the set value of "P_9: Electronic Thermal." | The load is too high. Too frequent rapid acceleration/ deceleration. | Reduce the load and operation frequency. |
| PS | PU Stop | The "STOP" button has been enabled by the setting parameter "P_75: Reset." | The operation has been stopped by the "STOP" button. | After turning off the servo, press the "STOP/RESET" button for recovery. Turn "on" the terminal "RES" for recovery. |
| CP | Parameter Copy | Parameter data has been copied between different AMSE controllers. | | Initialize the setting parameter "P989: Parameter Copy Warning Reset." |
| Fn | Fan Fault | The fan in the AMSE controller has failed and stopped, or its rotational speed has decreased. | Fan failure. | Contact the place of purchase. |
| oP | Hydraulic Control Board Warning | Setting error. | Mismatch between the combination use setting area and the combination use setting parameter. | See "8: Combination use" to check the setting of combination/single use. |

Table 7.2e Measures Against Error Messages

| Alarm | Name | Description/Cause | Remedy |
|-------|---|--|---|
| HOLD | Operation Panel Lock | The operation lock mode is active. | Press the "MODE" button on the operation panel for 2 seconds or more (to disable the operation lock). |
| Er 1 | Write Protection Error | The setting parameter "P_77: Parameter Write Selection" has been set to "1." | Change the setting of "P_77: Parameter Write Selection." |
| | | The operation panel has not been mounted to the AMSE controller properly. | Check the connection between the operation panel and the PU connector. |
| Er 2 | Write During Operation | A write was performed during operation with STF (STR) - SD set to "on." | Stop the operation. Change the setting of "P_77: Parameter Write Selection." |
| Er 3 | Modify the settings of the setting parameters (default settings are recommended). | | |
| Er 4 | | | |
| rE 1 | Parameter Read Error | EEPROM failure on the operation panel side during work. | Perform the work again. |
| | | | Operation panel failure. |
| rE 2 | Parameter Write Error | A write of copied parameter data was attempted during operation. EEPROM failure on the operation panel side during work. | Stop the operation and perform the work again. |
| | | | Operation panel failure. |
| rE 3 | Parameter Cross Check Error | Inconsistency of data on the operation panel with data on the AMSE controller. EEPROM failure on the operation panel side during work. | Press the "SET" button to continue the cross check process. When the error indication remains on, operation panel failure should be suspected. |
| rE 4 | Model Error | The AMSE controller model is different upon parameter copy, write, or cross check. Termination of parameter write after termination of parameter copy. | Check that the same model is used. |
| | | | Perform the work again. |
| Err | Error | The "RES" signal is "on." Failure of communication between the operation panel and the AMSE controller. The main circuit power separate from the control circuit power has been turned "on." | Turn "off" the "RES" signal. |
| | | | Check the connection between the operation panel and the AMSE controller. |

Table 7.2f Status Display

| | | | |
|------|----------------|-----------------------------------|---|
| ENIG | Emergency Stop | The unit is in an emergency stop. | Reset the emergency stop state. For the setting for combination use, see "8: Combination use." |
|------|----------------|-----------------------------------|---|

7.3 Measures against noise

- There are two types of noises: external noises causing malfunction of the AMSE controller and noises radiated by the AMSE controller and causing malfunction of peripheral devices. The AMSE controller is designed to be noise resistant; however, basic measures described in 7.3.1 are required because the AMSE controller is an electronic device handling weak signals. The AMSE controller chops output signals at high carrier frequencies and may generate noises. If such noises cause malfunction of peripheral devices, noise control measures must be taken. Measures slightly differ depending on the noise propagation path.

7.3.1 Basic measures

- For the AMSE controller's power cable (I/O cable) and signal cable, avoid running the cables in parallel or bundling them. Wire the cables separately.
- For control signal cable, use twisted pair shielded cables. Connect the outer conductor of the shielded cable to the terminal SD.
- Provide single point grounding for the "AMSE controller" and "motor."

7.3.2 Measures against external noises causing malfunction of the AMSE controller

- Take the following measures if noise-generating devices (electromagnetic contactor, electromagnetic brake, and many relays) are installed near the AMSE controller and may cause malfunction of the controller.
- Provide surge suppressors to the noise-generating devices for noise reduction.
- Use a "ferrite core" for the signal cable.
- Use metallic cable clamps to attach the shield of the encoder connection cable and control signal cable.

7.3.3 Measures against noises radiated by the AMSE controller and causing malfunction of peripheral devices

- Noises generated by the AMSE controller are roughly classified into three types: noises radiated from the cables connected to the AMSE controller and its main circuit (I/O), those electromagnetically or electrostatically induced in the signal cables of peripheral devices near the main circuit power cable, and those propagating through power lines.




Fig. 7.3a Classification of Noise Types

Table 7.3b Measures Against Noises

| Noise Path | Measures |
|---------------|--|
| (1), (2), (3) | <p>If devices or signal cables that handle weak signals and are susceptible to noise (gauges, receivers, sensors, etc.) are housed together with the AMSE controller or installed near the controller, they may malfunction due to noise. Thus, the following measures must be taken.</p> <ol style="list-style-type: none"> 1) Design the system so that noise-susceptible devices are away from the AMSE controller as far as possible. 2) Install noise-susceptible signal cables away from the AMSE controller and its I/O cable as far as possible. 3) Avoid running the signal cables and power cable (AMSE controller's I/O cable) in parallel or bundling them. 4) Turn "on" the EMC filter on/off connector of the AMSE controller. 5) Provide a line noise filter for output to suppress radiation noises from wires. 6) The use of shielded wires for signal and power cables or the housing of such cables in separate metal ducts is effective. |
| (4), (5), (6) | <p>If a signal cable is run in parallel to the power cable or bundled with the power cable, electromagnetic or electrostatic noise may propagate through the signal cable, causing malfunction. Thus, the following measures must be taken.</p> <ol style="list-style-type: none"> 1) Design the system so that noise-susceptible devices are away from the AMSE controller as far as possible. 2) Install noise-susceptible signal cables away from the AMSE controller and its I/O cable as far as possible. 3) Avoid running the signal cables and power cable (AMSE controller's I/O cable) in parallel or bundling them. 4) The use of shielded wires for signal and power cables or the housing of such cables in separate metal ducts is effective. |
| (7) | <p>If peripheral devices are connected to the same power line as for the AMSE controller, noise generated by the AMSE controller propagates through the power cable, causing malfunction of the devices. Thus, the following measures must be taken.</p> <ol style="list-style-type: none"> 1) Turn "on" the EMC filter on/off connector of the AMSE controller. 2) Provide a line noise filter for the power cable (output cable) of the AMSE controller. |
| (8) | <p>If peripheral devices are wired to the AMSE controller to form a closed-loop circuit, leak current may flow through the ground wire of the AMSE controller, causing malfunction of the devices. In such cases, remove the ground wire of the devices to prevent malfunction.</p> |

Note) Turning "on" the EMC filter may cause the earth leakage circuit breaker to malfunction. Therefore, an earth leakage circuit breaker for high frequencies range must be used.




Fig. 7.3b EMC Filter Switch




Fig. 7.3c Line Noise Filter

8. Combination use

8.1 Overview

The combination use of multiple ASE units can provide high flow with a system that requires high flow.

The control of combined pumps for combination use operation is performed by the “master ASE” unit, which allows combined “slave ASE” units following the master ASE unit to actualize the same operation (at the same speed). Therefore, it is only the master ASE unit that receives and processes pressure/flow commands and sequence signals. This mechanism can reduce the load of the main system’s sequence signals.

For the combination use operation, the communication network is configured so that the entire ASE system is urgently stop by the fail safe function when a failure occurs in a unit.

This control system is capable of controlling up to 16 combined units, or 3200-L/min flow (ASE10- × 16 units).

The controller can be used for both combination and single use operation; the operation mode can be switched by changing the settings.

8.2 Simplified diagram of the hydraulic circuit and wiring

- Directly connect all discharge lines.
- Only one pressure sensor mounted on the master ASE is used.
(No pressure sensor of the slave ASE units is used.)
- Sequence signals received by one unit for combination use operation are used for all combined units.




Fig. 8.2a Simplified Circuit Diagram for Combination Use

8.3 Component setting for combination use

* For components other than those shown below, see Section 4.




Fig. 8.3a Component Setting for Combination Use

8.5 Setting

Settings selected by the switches described in this section are not reflected if they are changed during operation. To make settings valid, select settings by these switches while the main power is "off," then, turn it "on."

8.5.1 Network No. selection switch for combination use (SW2)



Set network Nos. to each AMSE controller according to the number of combined units. Referring to the table below, set Nos. and roles to each AMSE controller. The default setting is "0."

* Turn the switch so that the arrow points a desired No.

Fig. 8.5a Network No. Selection Switch for Combination Use

Table 8.5a

| Number of combined units | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
|--------------------------|---|----|----|----|----|----|----|----|----|----|-----|-----|-----|-----|-----|-----|
| No. | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F |
| Role | M | S1 | S2 | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 | S11 | S12 | S13 | S14 | S15 |

Note) Meaning of Role: M = Master ASE, S* = Slave ASE

* No. for the AMSE controller for the master ASE is "0."

* Set Nos. other than "0" for the AMSE controllers for the slave ASE units. Setting the same No. for different slave units displays a warning "oP," rendering the system inoperable.

* The switch turns 360 degrees clockwise and counterclockwise. Turn the switch so that the arrow points a desired No.

8.5.2 Control switch for combination use (SW1)

Select settings by switching each bit between ON and OFF.




Fig. 8.5b Control Switch for Combination Use

Table 8.5b

| bit | Name | ON/OFF | Description | Default |
|-----|--|--------|---|---------|
| 1 | Manufacturer-controlled | | Changing the setting of "OFF" to "ON" is not allowed. | OFF |
| 2 | Reserved | | | |
| 3 | Switching combination/ single use operation | ON | Single use operation | ON |
| | | OFF | Combination use operation | |
| 4 | Network termination resistor | ON | w/ termination resistor | OFF |
| | | OFF | w/o termination resistor | |

■ bit.1 (manufacturer-controlled)

* The default setting is "OFF."

Table 8.5c

| ON/OFF | Mode |
|--------|---------------------|
| ON | Do not set to "ON." |
| OFF | Normal mode |

■ bit.2 Reserved

This bit is reserved.

* The default setting is “OFF.”

■ bit.3 Switching combination/single use operation

This bit is used for a model with a controller for combination use to perform single use operation.

* Switching this switch alone does not allow single use operation.

For details, see Section “8.9.”

* The default setting is “ON (single use operation mode).”

Table 8.5d

| ON/OFF | Mode |
|--------|---------------------------|
| ON | Single use operation |
| OFF | Combination use operation |

■ bit.4 Network termination resistor

In the combination use operation of the ASE units connected by a communication network, only one modular cable is connected to each of the AMSE controllers at both ends.

For such AMSE controllers, of which only one port of the modular connector is used, set bit.4 Network termination resistor to “ON.” Failure to do so may cause communication errors.

* The default setting is “OFF (w/o termination resistor).”

Table 8.5e

| ON/OFF | Mode |
|--------|--------------------------|
| ON | w/ termination resistor |
| OFF | w/o termination resistor |

<Example of termination resistor setting>





Fig. 8.5c Network Cable Connection

8.5.3 Modular connector (CN3)



This connector is used for connecting modular cables to configure a communication network connecting between the Master ASE and a slave ASE unit and between the slave ASE units.

Though, two cable ports are provided, there is no priority order between the two cable ports. When using only one cable, it can be connected to either port.

Connect cables, paying attention to the direction of the connector.

Fig. 8.5d Modular Connector

8.7 Before commissioning CAUTION

Preparation for operation is assumed to be completed. However, a breakage accident in a system for combination use may cause major damage. Recheck the followings before commissioning.

8.7.1 Checking the hydraulic circuit

Check that all discharge hydraulic lines are connected directly to the discharge hydraulic circuit without valves.

DANGER

If any discharge port of the slave ASE units is connected to another line or blocked for some reason, abnormal pressure may occur.
When stop valves are provided in pump discharge hydraulic lines for maintenance purpose, be sure to “open” the stop valves.

8.7.2 Checking the installation standards

Check the installation standards for ASE pumps and AMSE controllers.
In particular, pay attention to the cooling (distance between the fan and the wall).

8.7.3 Checking the cable connection

Only the master ASE requires the same cable connection as in single use operation. The slave ASE units require no pressure sensor cable.

DANGER

Incorrect cable connection may cause damage to the system and result in a fatal accident. Referring to this manual, recheck that the cable connection is correct.

8.7.4 Checking the setting of the controllers for combination use

1) Checking the network No. selection switch for combination use

- (1) For the AMSE controller for the master ASE, the setting should be “0.”
- (2) For the AMSE controllers for the slave ASE units, the setting should be “1 to F.”
The same No. cannot be shared between the combined slave ASE units.

2) Control switch

- (1) For the controllers with one modular cable connected, only bit “4” should be set at “ON.”
- (2) For the AMSE controllers for the slave ASE units with two modular cables connected, all bits should be set at “OFF.”

WARNING

When bit “3” of the control switch is set at “ON,” single unit operation may start. This may result in burnout of the AMSE controllers for other ASE units.

8.7.5 Checking the control parameter

* This involves powering on of all ASE units. Check that there is no incorrect cable connection.

(1) Power on the slave ASE units. There is no priority order between the units.

Note) This operation displays a warning “oP” but this does not matter.

(2) Check that the correct number of combined units is set for Parameter P449 (Number of combined units) of all the AMSE controllers for the slave ASE units.

(3) After checking the above (1) and (2), power on the master ASE.

Note) When Servo On starts concurrently with powering on, the system may start abruptly.

Check the safety around the system before powering on.

(4) Power on the master ASE. After setting the parameter, the preparation is completed.

(5) After checking the safety around the system, start commissioning by applying Servo On signals.

Note) If the system does not start, see “8. 8 Troubleshooting during combination use operation.”

■ Setting procedure (for reference)

(1) Check that the AMSE controller is powered on.

(2) Display P*** by pressing “MODE” for several times.

(3) Display P449 or P 17 by turning the “M dial.”

(4) Keeping this setting, turn the “M dial” to display a desired value and press “SET.”

(5) When the parameter is properly set, the parameter No. and the set value blink alternately.

(6) After setting, power “off” the AMSE controller, and then, power it “on” again.

(7) The setting is completed.

* Repeat this procedure to all applicable AMSE controllers.

* If the parameters are set improperly, the unit may become inoperable.



MEMO

8.8 Troubleshooting during combination use operation

No alarm is displayed for the controllers for combination use.

When a setting error occurs, a warning “oP” is displayed on the operation panel.

While “oP” is displayed, the system becomes inoperable. The system remains inoperable until proper setting is achieved. If “oP” is displayed in Servo On state, be careful because the system starts as soon as “oP” is turned off after the error cause is removed.

For other alarms and warnings, see “7. Troubleshooting.”

The table below lists conditions where alarms are displayed.

Table 8.8a

| Item | Condition |
|------|--|
| (1) | When power is not applied to all combined ASE units yet, the warning is displayed on the AMSE controllers for the ASE units with power already applied. |
| (2) | When the “network No. selection switch for combination use (SW2)” of the AMSE controller for the master ASE is set at a value other than “0,” the warning is displayed on all AMSE controllers. |
| (3) | When the same No. is set to the “network No. selection switch for combination use (SW2)” of different slave ASE units, the warning is displayed on all AMSE controllers. |
| (4) | When all ASE units are not connected with modular cables, the warning is displayed on all AMSE controllers. |
| (5) | When an alarm occurs in one of the combined ASE units, the warning is displayed on all AMSE controllers, excluding that for the unit generating the alarm. |
| (6) | When the set value for Parameter No. P449 is not consistent with the number of combined units in any one of the combined ASE units, the warning is displayed on all AMSE controllers. |
| (7) | During emergency stop, the warning is displayed on all AMSE controllers, excluding that for the master ASE (master “oP”). |
| (8) | “EPG” is displayed on the AMSR controllers for the slave ASE units for which “deactivation of servo emergency stop (EMG) (see Section 8, 6.2B)” is not set, while “oP” is displayed on the other AMSR controllers. |

If a warning “oP” is displayed, the system returns to normal operation with the removal of the cause.

To prevent unexpected accidents, consider and check the safety around the system in its power-on state.

9. Maintenance

This product requires no periodic overhaul during normal operation.

CAUTION

- ◆ Maintenance should be performed by a qualified person who has adequate knowledge of electrics and hydraulics (skilled worker equivalent to the 2nd grade Certified Skilled Worker of Hydraulic Device Assembly (Yuatsu Kiki Chosei Ginoshi) or higher or who has received our technical training).

9.1 Contamination control of hydraulic fluid

Foreign matter in hydraulic fluid often obstructs normal operation of the pump. It may cause failure or shorten the pump life. Keep hydraulic fluid clean (contamination level: JIS B9933 (ISO 4406) 20/18/14 or within NAS 9 class or better). Also, apply 100 µm (150 mesh) filters to the suction line and 10 µm or less filters to the discharge or return line.

9.2 Daily inspection

Perform daily inspections for the items in Table 9.2a.

The items listed below are standard check points after general hydraulic equipment has started steady operation. The frequency of inspection should be increased for a while after the initial operation. Taking into account the operational status/operating environment, perform maintenance, including maintenance of the actuator, as elaborately as possible.

Table 9.2a Daily Inspection Items

| Inspection Place/Item | Frequency | Inspection Method and Measure |
|---|------------|--|
| (1) Pump Noise | Once a day | When abnormal noise (differing from the normal sound of operation) occurs, stop operation and check the pump. |
| (2) Operating Condition of the Cylinder | Once a day | Check for any unstable phenomenon, including knocking. When detected, stop operation and check the cylinder. |
| (3) Rusty/Loose Joint | Once a day | Check that there is no looseness of or no dust/water entering the joints. |
| (4) Fluid Leakage | Once a day | Perform periodic inspection to prevent fluid leakage. When the fluid level is considerably lowered due to fluid leakage, pump performance may be degraded. Fluid leakage must be avoided to ensure against fire. |

9.3 Inspection of the AC servo motor

Employing a brushless motor makes daily inspection of the AC servo motor easy. Use Table 9.3a for reference. Determine the appropriate inspection frequency in terms of the operational status/operating environment.

Table 9.3a Inspection of the AC Servo Motor

| Inspection Place/Item | Frequency | Inspection Method and Measure |
|----------------------------------|---|---|
| (1) Vibration and Acoustic Check | Once a day | Comparing to normal conditions, check that there is no increase in vibration and noise by touch and by listening. |
| (2) External Inspection | Depending on damage | Clean with cloth or air, if required. |
| (3) Overall Check | Once every 20000 hours or every 5 years | Contact the place of purchase or our customer support |

9.4 Guideline for replacing the AC servo motor components

See Table 9.4a for component replacement intervals. The replacement period may vary depending on the condition of use or the operating environment. Replacement is required every time any failure is found. Contact the place of purchase or our customer support to request for component replacement. The requirement of component replacement will be determined after inspection.

Table 9.4a Component Replacement Intervals for the AC Servo Motor

| Component | Replacement Interval | Remarks |
|-----------------|----------------------|---|
| (1) Bearing | 20 thousand hours | When any failure is found, replacement is required even before the specified interval is reached. |
| (2) Cooling Fan | 20 thousand hours | |

9.5 Inspection of the AMSE controller

No daily inspection is required. Inspect the controller at least once a year.

Table 9.5a Inspection of the AMSE Controller

| Inspection Place/Item | Interval | Inspection Method and Measure |
|----------------------------|------------------------|---|
| (1) External Inspection | Once a year (at least) | Check that there is no dust, dirt, or oil contamination. If required, perform cleaning with cloth or air. |
| (2) Check for Loose Screws | | Check for loose mounting screws for the terminal block or connectors. If required, retighten them. |

9.6 Guideline for replacing the components of the AMSE controller

The electric or electronic components of the AMSE controller are subject to mechanical wear and aging. Periodically inspect them as part of preventive maintenance. Also, contact the place of purchase or our customer support according to Table 9.6a Component Replacement Intervals for the AMSE Controller. The requirement of component replacement will be determined after inspection. For the AMSE controller returned to/overhauled by us, parameter settings are reset to default values before shipment. Be sure to use the controller after setting the parameters appropriately.

Table 9.6a Component Replacement Intervals for the AMSE Controller

| Component | Standard Replacement Interval | Remarks |
|--------------------------------------|--|---|
| (1) Cooling Fan | 10 years | When any failure is found, replacement is required even before the specified interval is reached. |
| (2) Main circuit smoothing capacitor | 10 years (assuming the annual average ambient temperature of 40 °C) | |
| (3) On-board smoothing capacitor | 10 years | |

10. Storage of unused units

Store and manage unused and spare units in a proper indoor storage place.

- Storage temperature range: 0 to 40 °C (no freezing)
- Storage humidity range: 80 % or less (no condensation)
- To avoid rust, corrosion, degradation of seals, etc., do not store the unit in the following and similar places.
 - a) Places potentially exposed to the direct influence of weather
 - b) Places where chemicals, such as organic solvents, acids, and alkalis, are present or the effect of vaporized gas potentially exists
 - c) Places where dew condensation potentially occurs due to substantial temperature fluctuations.

11. Disposal

This unit is categorized as industrial waste for the purpose of disposal. When disposing of the unit, its components, and hydraulic fluid, follow the procedures set out in the Waste Disposal and Public Cleansing Law and have them disposed of by an industrial waste disposal contractor.

12. Customer service

If there are requests regarding our products or if any services are required, please contact the place of purchase, our customer support, or the following sales department.

- YUKEN KOGYO CO., LTD.

International Sales Department
 4-4-34, Kamitsuchidana-Naka, Ayase,
 Kanagawa Pref. 252-1113, Japan
 Phone +81-467-77-3111
 Fax +81-467-77-3115

- YUKEN EUROPE LTD.

51 Spindus Road, Speke Hall
 Industrial Estate, Liverpool L24 1YA,
 United Kingdom
 Phone +44-151-486-4696
 Fax +44-151-486-3537

- History of Publication

ASE AC Servo Motor-Driven Pump Operation Manual

December 2009 First edition of the English version Pub. EM-0146

July 2013 9th edition of the English version Pub.EM-0146-8

- Published by:

● YUKEN KOGYO CO., LTD.

Products Publicity Section, Sales Administration Dept.

Hamamatsucho Seiwa Bldg., 4-8, Shiba-Daimon 1-Chome
Minato-ku, Tokyo 105-0012, Japan

Phone: +81-3-3432-2113 Fax: +81-3-3436-2344